

BLUESOUND N530 Node Icon Digital Player User Guide

Home » BLUESOUND » BLUESOUND N530 Node Icon Digital Player User Guide 🖔

Contents

- 1 BLUESOUND N530 Node Icon Digital
- **Player**
- **2 Product Specifications**
- **3 Product Usage Instructions**
- 4 FAQ
- **5 ACCESSORIES**
- **6 Overview**
- **7 CONNECT FOR SOUND**
- **8 POWER ON**
- 9 LAUNCH THE BluOS APP
- **10 ADD TO THE NETWORK**
- 11 Contact
- 12 Documents / Resources
 - 12.1 References



BLUESOUND N530 Node Icon Digital Player



Product Specifications

- Accessories: 120V AC Power Cord, Ethernet Cable, 230V AC Power Cord, Stereo RCA to RCA Cable
- Features: Presets 1-5, Prev/Next Track, Volume Slider/Tap Display, Optical In, Coax Out, Analog In, Analog Out, Balanced XLR Out, Subwoofer Out, Optical Out, Play/Pause Status Indicator, Headphone Jack
- Connectivity: USB A In/Out, HDMI eARC, Trigger Out, IR In, AC Mains In, USB C In, LAN

Product Usage Instructions

Connect for Sound:

• Connect the Player to your audio system using one of the following options: Balanced XLR, Analog RCA, Optical, Coaxial, or USB.

Power On:

• Plug the Player into mains power and look for setup information on the display.

Launch the BluOS App:

• Open the BluOS app on your device.

Add to the Network:

• Follow the Add A Player wizard in the BluOS app to complete the setup or navigate to the Players page and press the + icon.

FAQ

Frequently Asked Questions

- Q: How do I access the user manual online?
 - A: You can scan the QR code provided in the manual to access the user manual online. This will give you detailed instructions, troubleshooting tips, and additional information about your Player.
- Q: What should I do if I need help?
 - A: If you need help, you can visit support.bluesound.com or contact support@bluesound.com. For North America, you can call 1-855-531-4666 and for EU, dial 00 800 53 14 66 66.
- Q: Where can I download the BluOS Controller App?
 - A: You can download the BluOS Controller App from bluesound.com/downloads.

ACCESSORIES










Stereo RCA to RCA Cable

Overview



CONNECT FOR SOUND

Connect the Player to your audio system using one of the following options: Balanced XLR, Analog RCA, Optical, Coaxial or USB



POWER ON

Plug the Player into mains power and look for setup information on the display




LAUNCH THE BluOS APP

Open the BluOS app on your device



• bluesound.com/downloads

ADD TO THE NETWORK



• Follow the "Add A Player" wizard in the BluOS app to complete the setup or navigate to the Players page and press the "+" icon.

Contact

Scan the QR code



 Scan the QR code to access the user manual online. Gain instant access to detailed instructions, troubleshooting tips, and additional information about your Player.

NEED HELP? GET IN TOUCH

• support.bluesound.com

• support@bluesound.com

• North America: 1 855 531 4666

• EU: 00 800 53 14 66 66

bluesound.com

© Bluesound International. Bluesound, the stylized wordmark "B" logotype, the phrase "HiFi for a wireless generation", NODE ICON and all other Bluesound product names and taglines are trademarks or registered trademarks of Bluesound International, a division of Lenbrook Industries Limited. All other logos and services are trademarks or service marks of their respective owners.

Documents / Resources



<u>BLUESOUND N530 Node Icon Digital Player</u> [pdf] User Guide N530, N530 Node Icon Digital Player, Node Icon Digital Player, Icon Digital Player, Digital Player, Player

References

- 3 Wireless multi-room speakers and components for music streaming Bluesound
- SOVI
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.