



Bluestone SB23 PopBox Portable Speaker with Microphone User Manual

[Home](#) » [Bluestone](#) » Bluestone SB23 PopBox Portable Speaker with Microphone User Manual 

Contents

- [1 Bluestone SB23 PopBox Portable Speaker with Microphone](#)
- [2 INTRODUCTION](#)
- [3 PACKAGE CONTENTS](#)
- [4 PRODUCT OVERVIEW](#)
- [5 SPECIFICATIONS & FEATURES](#)
- [6 HOW TO USE](#)
- [7 CARE AND SAFETY](#)
- [8 Documents / Resources](#)
- [9 Related Posts](#)

Bluestone.

Bluestone SB23 PopBox Portable Speaker with Microphone




INTRODUCTION

Have you been looking for a new speaker to take to the park? This one is the perfect park pal! Its stunning front face is a real head turner. It has a beautiful light up design in the front that will attract crowds. The sound is perfect for a day at the park with the kids or a day at the park with the dogs. Everyone will get a kick out of this speaker. And when listening to music isn't what you want anymore, there's a karaoke feature to spice it up! Everyone will have a blast with this speaker.

PACKAGE CONTENTS

- 1x Speaker
- 1x Microphone
- 1x Charging Cable

PRODUCT OVERVIEW



SPECIFICATIONS & FEATURES

- Speaker is approx 25 in x 7.25 in x 4.25 in
- Bluetooth: 3
- Woofer Size: 5"
- Woofer Output: 1000W
- Range: 33ft
- Battery: 1200mAh
- Playing time: Up to 5 hours
- Charge Time: 3 hours
- True Wireless Capabilities
- FM Radio
- Inputs: AUX / USB / MicroSD
- Karaoke Mic

HOW TO USE

Using MicroSD (TF) Card Slot – Max Capacity is 16GB

1. Insert the Micro SD (TF) Card or USB Drive preloaded with songs
2. Speaker will automatically start playing songs
3. During playback, short press the Previous button to go back to the previous track, press the Next button to skip to the next track.

Using Bluetooth

1. Power on the product to enter into BT mode.
2. Search for and select “PopBox” on your external Bluetooth device.
3. The speaker will issue an indication tone after successful connection.

Using Radio

1. Press the mode button and choose FM mode.
2. Short press Play/Pause button to begin scanning for all available stations.
3. Short press it again to stop searching.
4. Press Next button to select the next stations.

Using AUX

1. Power on the unit, and cycle through Modes to the AUX N selection.
2. Plug your AUX Cable in the AUX N Port and use device to select/play music.

Using Karaoke

1. Insert the plug of the Microphone into the unit's M C jack.


CARE AND SAFETY

- Do not use this unit for anything other than its intended use.
- Keep the unit away from heat source, direct sunlight, humidity, water or any other liquid.
- Do not expose the device to extremely high or low temperatures, as it may damage the battery.
- Do not operate the unit if it has been wet or moist to prevent against electric shock and/or injury to yourself and damage to the unit.
- Do not use the unit if it has been dropped or damaged in anyway.
- Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
- Keep the unit out of reach of children.
- This unit is not a toy.

BATTERY DISPOSAL:

This product contains a lithium polymer battery. Lithium polymer batteries are environmentally safe when fully discharged. Please refer to your local and state laws for battery disposal procedures.

Documents / Resources



[Bluestone SB23 PopBox Portable Speaker with Microphone](#) [pdf] User Manual
SB23, PopBox Portable Speaker with Microphone, SB23 PopBox Portable Speaker with Microphone