



# boAT Wave Electra User Manual

[Home](#) » [Boat](#) » boAT Wave Electra User Manual 

## Contents

- 1 boAT Wave Electra
- 2 CHARGING THE WATCH
- 3 CONNECTING TO THE APP
- 4 SYNCING YOUR SMARTWATCH TO THE APP
- 5 Settings
- 6 Heart Rate Monitor
- 7 SWIPE UP TO VIEW YOUR NOTIFICATIONS
- 8 PRODUCT PARAMETERS
- 9 MAINTENANCE
- 10 SAFETY & PRODUCT INFORMATION
- 11 Documents / Resources
- 12 Related Posts


# Boat

**boAT Wave Electra**



## CHARGING THE WATCH

The smartwatch must be charged before initial use. It takes 2 hours to be fully charged. Connect and charge the watch with the image below as a reference, using a 5V/2A adapter.



## TURNING THE WATCH ON/OFF

To turn the watch on/off, long-press the side button for 3-5 seconds. You can wake the screen by lifting your wrist



## CONNECTING TO THE APP

- Download the boAt Wearables app on your phone Available on both App Store (iOS 12.0 and above) & Google Play Store (Android 7.0 and above)



- Connect the device with the boAt wearables app
- Select Electra on the home screen of the app and click pair to connect.
- Click on “pair” when you get a prompt to connect with Electra\_BT, This is required if you want to attend calls on your watch.
- Alternatively, you can go to your phone’s settings and pair Electra\_BT manually.
- To use all features of your Wave Electra seamlessly, tap on ‘yes’ to the ‘connection’ and ‘grant access” system prompt.
- Turn your phone’s Bluetooth and GPS on.
- Disable battery optimization



## **SYNCING YOUR SMARTWATCH TO THE APP**


### **Data Synchronization**

- Open the app on your phone.
- Make sure your wave Electra is connected to the app
- Synchronization will start automatically once you enter the app interface

## **NAVIGATING THROUGH THE FUNCTIONS SWIPE RIGHT FOR MAIN MENU**

### **Sports**

- Tap on the sports icon to choose from 100+ sports modes: Run Walk, Indoor Walk, Outdoor
- Cycle, Climbing, Yoga, Basketball, Football, Badminton, Skipping. Swimming. Cricket,
- Volleyball, Hockey. Judo, Rock Climbing, Air walker Archery. Ballet Baseball, Beach
- Volleyball, Billiard, Bowling, Break Dance, Cross Country Sking Curling, Darts, driving, Folk
- Dance, Frisbee, Hula Hoop, Jujitsu, Kite Flying, Line Skating, Break
- Dance and more
- Tap on your preferred activity to begin
- To pause or stop the exercise, press the home button, click finish to end the exercise.



## WATCH FACES

- Tap on this icon to change your watch face. Alternatively, long press the home screen to change the watch faces
- There is total 20 built-in watch faces in the watch and 100+ available on the cloud, which can be accessed through the app



## Menu Style

Tap on this to change the app view. (List and grid view)



## Shutter

Tap on this icon to access remote camera. Make sure your watch is connected with the app



### Find My Phone

Wear the watch on your wrist, then click on the icon to start measurements. You can also view the data on the app.



### Blood Oxygen Level Monitor

Wear the watch on your wrist, then click on the icon to start measurements. You can also view the data on the app.



### Stopwatch

Tap on this to access stopwatch.




### Countdown

Tap on this to access the countdown.



### Phone

Tap on this to access Favourite contacts, Call History&



### Dialer from here.

Add your contacts on the phonebook from the boAt Wearables app. You can add up to 50 contacts



### Guided Breathing Mode

Click on the breath training icon to regulate your breathing with the instructions given to relax.



### Alarm Clock

Tap on this to access alarms



### Calendar

Tap on this to check the calendar.



## Calculator

Tap on this to access the calculator



## Settings

You can access the screen off, QR code, Reboot, Reset, Power Off, and About from this menu.



## BT Calling



- You can access the BT calling feature from the shortcut menu in the main menu.
- To use the BT Calling feature, open the boAt Wearables app and pair the watch.
- Once paired you will get the pop-up on the app home screen to connect with the Phone's Bluetooth.
- Click on "pair" to connect with the phone's Bluetooth
- Alternatively, you can go to the phone's Bluetooth settings and pair "Electra\_BT" to start the calling feature on your watch
- Up to 50 contacts can be saved in the phonebook.
- Call history will show the latest call details.
- Use a dialer to dial any number

## Heart Rate Monitor

Wear the watch on your wrist, then click on the icon to start measurements. You can also view the data on the app.




## Weather

Tap on this to know weather forecasts. "Enable weather feature from the app first



## Music Control

Tap on the remote music control icon on your Wave Electra to play music from your phone.



## SWIPE UP TO VIEW YOUR NOTIFICATIONS



## SWIPE LEFT TO ACCESS ALL DATA

You can access daily activity data, heart rate, sleep, weather, and other widgets.



## SWIPE DoWN FOR SHORTCUT MENU

You can access Power off, games, Screen off duration, phone. Voice Assistant, Reboot, DND, Brightness, settings, QR Code, Lock Screen & Flashlight from here.





## PRODUCT PARAMETERS

Model	boAt Wave Electra
Screen type	1.81" Big Display
Battery capacity	240 mAh
Net weight	40g
Bluetooth version	5.0
Working temperature	20-65°C
Charging time	up to 2 hours
Working time	up to 3 days with BT calling, up to 7 days without BT calling
Maximum transmit power	0
Frequency band	2402 - 2408

## MAINTENANCE

Regularly clean your wrist and the strap of the smartwatch, especially after sweating during exercise or being exposed to substances such as soap or detergent, which may get stuck on the other end of the product. Do not wash the strap with a household cleanser. Please use soap less detergent, rinse thoroughly and wipe with a piece of soft towel or napkin. For spots or stains that are not easy to remove, scrub the area with rubbing alcohol and then follow the above procedure

### Search for the app to connect keeps failing

- Keep the boat Wearables app updated to the latest version
- Close all the programs on the watch Stop and restart Bluetooth and GPS Connect again
- Check and enable notification functions of your phone and keep the phone and watch in close contact.

### My Wave Electra is receiving no alerts, texts, or phone calls

- Make sure smart reminders on the app are on and synced to the Wave Electra.
- Also make sure your notification center of the phone is displaying messages. Only then will your smartwatch also display those notifications.
- Make sure app is running in the background and battery optimization feature on the phone is disabled.
- Make sure Electra\_BT is connected from the phone to receive calls on the watch

### My Bluetooth keeps getting disconnected

- Make sure there is not more than 7m distance between Bluetooth on the phone and the watch.
- There is no obstacle in between the watch and the phone.

- Make sure the app is running in background.

### **Which functions of the Wave Electra need Bluetooth to work?**

Call & Text Notifications, music control, camera control, weather forecast, cloud and custom watch faces and Bluetooth calling need Bluetooth connectivity to work.

### **Will it be okay to take a bath wearing the Wave Electra?**

The IP68 water resistance will only work under the following conditions (1) Maximum depth of water 1.5m (2) Maximum time for exposure to water: 10 minutes The watch isn't suitable for hot baths, hot springs, saunas, snorkeling, diving, water skiing and other wading or deep-water activities with high-speed water flow.

### **How to use Bluetooth calling feature on the watch?**

- Open the boAt Wearables app, pair the watch with the app first.
- Once paired you will get the pop-up on the app home screen to connect with Phone's Bluetooth
- Click on "pair" to connect with phone's Bluetooth
- Alternatively, you can go to phone's Bluetooth settings and pair "Electra\_BT" to start the calling feature on your watch

### **How to add contacts in the watch?**

- Open App-> devices->device info-> contacts
- You can select up to 50 contacts from your phonebook which will be synced with the watch.
- Once you initiate the call from the watch, you can select caller name from the list or directly dial the number from the dialer.

## **SAFETY & PRODUCT INFORMATION**

### **Battery**

- Do not disassemble, bore or damage the battery.
- Do not disassemble the built-in batteries of non-replaceable battery devices.
- Do not use sharp objects to remove the battery.

### **Health Warning**

- If you are wearing a pacemaker or other implanted electronic devices, please consult your doctor before using the heart rate monitor of the watch.
- The optical heart rate sensor will glow green.
- If you suffer from epilepsy or are sensitive to blinking light sources, please consult your physician before wearing this device.
- The device tracks your daily activities through sensors.
- This data is intended to tell you about your daily activities such as steps, sleep, distance, heart rate and calories, but may not be completely accurate.
- The device accessories, heart rate sensor, oxygen level monitor, and other relevant data is designed for fitness and not for medical purposes.

- They are not applicable to the diagnosis, monitoring, treatment or prevention of any diseases or symptoms.
- The heart rate and blood pressure data is for reference only, We're not responsible for any deviation in data.

### Things to keep in mind


Sync data everyday to avoid data loss. Water Resistance will not work for seawater, acidic and alkaline solutions, chemical reagents and other corrosive liquid. The damage or defects caused by misuse or improper use are not covered by the warranty. Sports modes support up to 6 hours of exercise at a time. Avoid wearing the watch too tight in daily use. Keep the parts of skin touching the watch dry. Keep your arm still while measuring data for accurate measurements

**Disclaimer:** This product is an electronic monitoring product and is not intended as a medical reference. We reserve the right to modify or improve any of the functions described in this manual without any prior notice. At the same time, we hold the right to continuously update the product content

### CAUTION

Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycle valuable raw materials and treatment of toxic substances.

### Documents / Resources

	<a href="#">boAT Wave Electra</a> [pdf] User Manual Wave Electra, Wave Smartwatch, Electra Smartwatch, Smartwatch
---	--