

BOBOLEE X17 Trackpad Keyboard Case for iPad 10th Generation Instructions

Home » BOBOLEE » BOBOLEE X17 Trackpad Keyboard Case for iPad 10th Generation Instructions



BOBOLEE X17 Trackpad Keyboard Case for iPad 10th Generation



Contents

- 1 Specifications
- 2 Operations
- 3 Keyboard Layout
- 4 Features
- **5 Indicators Descriptions**
- 6 Charging precautions
- 7 Touch pad gestures
- 8 Features Touch pad gestures Cleaning and maintenance
 - 8.1 Keyboard and cover care
 - 8.2 Battery maintenance
- 9 Troubleshooting
 - 9.1 About Connections
 - 9.2 Use of touch pad
- 10 Documents / Resources
 - 10.1 References
- 11 Related Posts

Specifications

- 1. Bluetooth standard port 5.2
- 2. Operation Range: within 10 meters
- 3. Modulation Mode: GFSK
- 4. Work Current: <10mA
 - (During Touch board is working)
- 5. Standby Current: <2mA
- 6. Sleep Current: <40uA
- 7. Charge Current: 100mA/200mA (with Backlight)
- 8. Standby Time: >100 days
- 9. Charge Time: 2~3 hours
- 10. Work time: ≥ 30/100hours
 - (Shut down backlight)
- 11. Lithium battery life: 3 years
- 12. Key strength:80+10g
- 13. Key life: 500 million clicks
- 14. Working Temperature: -10°C+55°C


Operations

For the first time use, charge it for 3~4 hours to make sure sufficient power.


Keyboard use:

- 1. Press the switch to power on/off the keyboard.
- 2. Press the buttons "Fn+C" to enter Bluetooth pairing mode, the indicator will start to flash blue color.
- 3. Open Settings—Bluetooth—My devices. Tap "Bluetooth Keyboard" to connect.
- 4. After paired successfully, the indicator will be turn Off.






Keyboard Layout



Note: The above is the function reference table, which shall be subject to the actual situation


Features





Backlight adjustment (optional)

Adjust three modes: press once to turn ON the light, press twice to make the light brighter, press three times to turn OFF the light;




Fn+Q Turn ON/OFF colorful breathing backlight

Fn+W Adjust colorful light speed



- 1. Operation System: IOS15.0 or above (The device must support Touch feature).
- 2. Tap settings (after successful wireless paired): settings general touch pad tap/double finger auxiliary point (open).
- 3. Sensitivity setup: setting general touch pad tracking speed (adjust to appropriate speed).
- 4. Touch pad (no physical buttons): no "drag" gesture function option.


Indicators Descriptions



① A Case indicator	Press "Caps Lock" on the keyboard, and the indicator t urns white.
②	Press Fn+C to enter Bluetooth pairing mode, the indic ator starts to flash blue, after successfully paired, the indicator will be turn OFF.
③ ★ Charging Indicator	The indicator is always on during charging, it will turn g reen or turn off after charging finished.
Power Indicator	Flashing blue means "Low Power".

Charging precautions

1. For the first time use, charge it use only the cable from manufacture.




2. When charging, check whether the charging port is powered normally.

Note: Do not charge the keyboard for a long time. Plugging in the keyboard for a long time will deplete its battery life.

Touch pad gestures

Tap: Press with a single finger until you f eel a touch.	Press: Press and hold with a single finger
Drag: Drag and hold the item, then slid e on the touch pad to move it	Wake up the iPad: Click the touch pad or tap any key if you are using an external keyboard.
Open the dock: Swipe the pointer with a single finger across the bottom of screen	Go to the home screen: Swipe the p ointer with a single finger across the bottom of screen. After the dock appears, swipe the pointer across the b ottom of screen again.
Display side pull: Use a single fi nger to swipe the pointer over the right edge of the scr een. To hide the side pull, swipe right again.	Zoom: The two fingers are placed cl ose, spread out to put large, or pinched to shrink.
Open Control Center: Move the pointer with a single finger to select the status icon at the top right, then click, or select the status icon at the top right, and then swipe up	Open the Notification Center: Move t he pointer near the top center of the screen with a sing le finger, or select the status icon at the top left, and th en click.



Features Touch pad gestures Cleaning and maintenance

In order to make your keyboard awesome and easy to use, please keep good use habits and pay attention to protecting the keyboard.

Keyboard and cover care

The keyboard is relatively light and thin. Please be careful not to use it on uneven surfaces to avoid bending the

keyboard. Do not apply the liquid directly on the keyboard. Use a lint free cloth dipped in alcohol or mild soapy water to wipe the keyboard and shell for maintenance. Clean your keyboard cover in this way often to make it look great.

Battery maintenance

Operating temperature: the operating temperature of the keyboard is 0 ° C~35 ° C. Lithium battery is very sensitive to high temperature, so keep its surface away from the sun and do not put it in a hot car. **Charging at any time:** You can charge the battery at any time even its power is not zero. However, do not charge for a long time, which will reduce the battery life.

Troubleshooting

About Connections

The keyboard only supports Bluetooth connection. Confirm that the keyboard and tablet are paired and connected before use. If the keyboard has the connection delay or input delay:

- 1. Fully charge the keyboard for 3-4 hours.
- 2. Delete all Bluetooth connections on the tablet, eliminate signals interference, turn off the Bluetooth function, and restart the tablet.
- 3. Close and open the keyboard, and press "Fn+C" to reopen the keyboard Bluetooth.
- 4. Open Settings Devices- My Device, find the "Bluetooth Keyboard" and click to connect.

Use of touch pad

Before using, make sure the touch function is turned on. If the cursor moves randomly, use a lint free cloth dipped in alcohol or mild soapy water to wipe the touch pad. Keep your hands dry during use to avoid incorrect gestures recognized by the touch pad.

Due to the upgrade of the system version or special customization of the APP program, it is normal that some shortcut keys cannot be used due to different functions. Please refer to the product details and function introduction, or consult the merchant customer service

Documents / Resources



BOBOLEE X17 Trackpad Keyboard Case for iPad 10th Generation [pdf] Instructions X17, X17 Trackpad Keyboard Case for iPad 10th Generation, Trackpad Keyboard Case for iPad 10th Generation, Keyboard Case for iPad 10th Generation, Case for iPad 10th Generation, iPad 10th Generation, 10th Generation, Generation

References

User Manual