




Bobtot EW9 Wireless Bluetooth Headset User Manual

[Home](#) » [Bobtot](#) » Bobtot EW9 Wireless Bluetooth Headset User Manual 

Bobtot®



EW9
Wireless Bluetooth headset

Model	EW9
Charging case socket	Type-c
Charging voltage	DC 5V
BT model	V5.0
BT protocol	HFP/HSP/A2DP/AVRCP
BT encoding	AAC/SBC
Sensing distance	10M

Contents

- [1 FCC Requirement](#)
- [2 Warm Tips](#)
- [3 Introduction](#)
- [4 MFB Touch Operation](#)
- [5 Charging Status](#)
- [6 About the Warranty](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)

FCC Requirement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warm Tips

1. For the first use, please fully charge the earbuds, then begin to use them.
2. When using mobile traffic to listen to songs online, the playback may be interrupted due to network speed, which is not a quality problem. We suggest all users should firstly download songs then listen to music.
3. This product contains a lithium battery inside. In order to protect the internal battery, please charge this product once a month!

Introduction



1. Touch Area
2. Horn Grid
3. Charging Case Indicator
4. Charging Case
5. Type-c Charging Port

Power On

1. Take out EW9 earbuds from the charging case then auto power-on.
2. Under power-off status, press & hold the power button for 3 seconds to power on.

Power Off

1. Put EW9 earbuds inside the charging case then it will power off and get charged automatically.
2. In not paired status, EW9 earbuds will power off automatically in 3 seconds.
3. Cancel the manual power-off function.

Power on prompt "Power On"

Power off prompt "Power Off"

Pairing

Both the left and right EW9 earbuds are turned on at the same time, then automatically paired and connected. After the pairing is successful, both earbuds come into the BT standby status.

BT Pairing

1. Both the earbuds enter the BT standby state, then we use a mobile phone to search for the BT device Bobtot EW9 and click to connect.
2. After power on, both the left and right EW9 earbuds will automatically connect back to the last connected

device. If there are no available pairing in 5 seconds, the earbuds will enter a BT standby status.

Reset

Press the power button 4 times continuously in 10 seconds after EW9 earbuds power on (If the 4-time-press in 10 seconds is successful, the earbuds will reset to the factory settings and enter the TWS pairing mode. The TWS pairing mode lasts for 15 seconds). If we make no operation in 10 seconds after power-on, EW9 earbuds just turn on as normal (Applicable status: When TWS is not connected successfully and when TWS is connected successfully).

MFB Touch Operation

Answer the call: Twice press the L/R MFB button.

Reject the call: Press and hold the L/R MFB button for 2 seconds.

Hang up: When calling, twice press the L/R MFB button.

Play/Pause: When playing music, twice press the L/R MFB button.
Play the music or pause the music

Previous: Continuously press the L MFB button 3 times.

Next: Continuously press the R MFB button 3 times.

Voice Wake-up: Press and hold the MFB button for 2 seconds in non-call mode.

In-ear detection: Remove any earphones, pause other music, wear EW9 earbuds and play the music.


ENC call noise reduction

When we wear BT earbuds for calling, the call noise reduction function will be automatically turned on.

Charging Status

1. When EW9 earbuds are charging, the red indicator is always on.
After fully charged, the red indicator will turn off automatically.
2. When the charging case is charging, the orange indicator is always on. After fully charged, the orange indicator will turn green and always on.

5V DC adapter




About the Warranty

1. We provide a one-year warranty service.

2. Man-made damage is not warranted.
3. Customers must offer the necessary information(Order ID, Order Platform).
4. To redeem the warranty, please email us at service@bobtot.net for further assistance.

Documents / Resources

	<p>Bobtot EW9 Wireless Bluetooth Headset [pdf] User Manual EW9, 2AZ43-EW9, 2AZ43EW9, EW9, Wireless Bluetooth Headset</p>
---	--

[Manuals+](#)