



# bol media Digital alarm clock with USB Port Instruction Manual

[Home](#) » [bol media](#) » bol media Digital alarm clock with USB Port Instruction Manual 

## bol media Digital alarm clock with USB Port Instruction Manual

### Contents

- [1 Product Parameters:](#)
- [2 Functions:](#)
- [3 SETTING INSTRUCTION](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

### Product Parameters:

Power supply: DC 5V—2A, AC100-240V 50/60HZ

In order to ensure the charging speed and the stability of product function, the product needs to use the USB cable with 2A electric current+ DC5V/2A power adapter Power: 5W

Charging distance: 2-10mm (the closest distance between the mobile phone and the product, the faster charging)

Charging time: about one hour more compared with plug-in charging.

Usage: When the clock is plugged in, put the phone on the top of the clock, and the phone can be charged.

### Functions:

#### Display mode:

There are two display modes, press the button “SET”, and you could change the mode of display;

Dp-1: time, temperature, and year, month, and day display would change orderly(Carousel mode)

Dp-2: only time, temperature display (Fixed mode)

#### Voice Mode Mode (power-saving mode):

Press the button “DOWN”, on Sd“←→”—: Sd”; “on Sd” means sound control in on; “—: SD” means sound control is off.

It will automatically close the voice mode in seconds; the Display will woke up when the sound is louder than 60 decibels or flapping the clock. If close the voice control mode, the constant light function will be opened.

### Temperature Mode Setting:

Press the button of “UP”, and you could change the Temperature Mode between °C and °F

### **Brightness Setting:**

Press the button “UP” for 3 seconds, you could enter into the mode of brightness, then you could change the brightness by pressing the button “UP”(more bright) and pressing the button “DOWN”(less bright).

L1: Bright

L2: Less Bright

L3: Weakest brightness

### **Power supply:**

Because this clock with LED light, is more power-consuming. It is not recommended to use an AAA battery power supply. We recommend using a USB cable supply power directly.

It must use a plugged-in power supply when charging the phone.

(The clock with a built-in cell battery, will automatically remember the time when the power is off, we don't need to reset the time);

### **Alarm Setting:**

Users can set 3 alarm times every day, alarm lasting 1 minute, the sound is: beep beep beep can press any key on the back of the clock to stop the alarm;

## **SETTING INSTRUCTION**

Press the button “SET” (While the numbers flash), you would enter into the setting mode. And the setting order is as follows:

### **1. Setting of Date**

When entering the set mode, the letter flashing setting order “Year” “Month” or “Day”, press the button “UP” or “DOWN” to change the number.

### **2. 12H/24H Setting**

After finishing the setting of the date, you would enter into the 12H/24H Setting mode while you press “SET”, and also you could change the 12H/24H by pressing the “UP” and “DOWN”. At the 12H Setting mode, PM lights are on.

### **3. Time Setting**

After finishing the date setting mode, you could enter into the time mode setting while you need to press “SET” and then you could adjust the time by pressing “UP” and “DOWN”.

### **4. Alarm Setting**

After finishing the time mode setting, you could enter into the alarm setting while you need to continue press “SET”, and then you could adjust the time by pressing “UP” and “DOWN”.

Press “UP” and “DOWN” can adjust upward or downward to open on A1/Close -:

A1. When the letter “on A1” appears, you could press “SET” and enter into A1 Alarm clock Setting(you could set 3 Alarm clocks A1/A2/A3 ). Then the letter of time “-” flashes, and you continue to press “UP” and “DOWN” to set alarm.

You could continue to set the Alarm clock A2/A3 following steps 1 and step 2.

### **5. Alarm Setting For Work Day**

After finishing the alarm setting, press the key “SET”. Then you could press “UP” and “DOWN” to change the status of the on/off the workday alarm. (on E means on; -: E means off.)



12H PM



Turn off Alarm

Turn on Alarm 1



Turn off Alarm 3



Turn on voice control




Turn off voice control



Turn on workday alarm



Turn off workday alarm



• SET	• RESET
• UP	• DC5V
• DOWN	

#### Tips:

- If use the AAA battery, it means that the battery is not enough when the numbers flashing. Please replace it in time or use USB cable. Normally, the AAA battery will dead in 5-7 days, we recommend to use USB cable directly.
- When the function is abnormal or the display is abnormal (such as nothing happened in the screen when the power is plugged in or the battery is installed), press the RESET button on the back of the product, reactivate.
- If the mobile phone without wireless charging receptor function, you need to equip the wireless charging receptor based on the mobile phone model. Please following below steps:

## Iphone Port

Iphone receptor  
Please noted the port




## Android Port

Type-C port  
Narrow top wide below



**Step 1:** The receptor is plugged into the charging port.



**Step 2:** Fixed the receptor on the back of the phone.




**Step 3:** Charging the clock



**Part 4:** Put the phone on the top of clock (the receptor is aligned with the clock transmitter), the phone is charging.



## Documents / Resources

	<p><a href="#">bol media Digital alarm clock with USB Port</a> [pdf] Instruction Manual Digital alarm clock with USB Port, clock with USB Port, USB Port</p>
---	--