



BOOGIIO B1dSwsN2JUL Wireless Keyboard and Mouse Combo User Manual

[Home](#) » [BOOGIIO](#) » BOOGIIO B1dSwsN2JUL Wireless Keyboard and Mouse Combo User Manual 

Contents

- [1 BOOGIIO B1dSwsN2JUL Wireless Keyboard and Mouse Combo](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Package Contents](#)
- [5 Specification](#)
- [6 Product Layout](#)
- [7 Keys & Functions](#)
- [8 Operating Steps](#)
- [9 Features](#)
- [10 Safety Instructions](#)
- [11 Troubleshooting Steps](#)
- [12 Federal Communications Commission Statement](#)
- [13 Documents / Resources](#)
 - [13.1 References](#)

BOOGIIO

BOOGIIO B1dSwsN2JUL Wireless Keyboard and Mouse Combo



Product Information

The 2.4G Wireless Keyboard & Mouse Combo Set (Model: K893G/M893G) is a package that includes a wireless keyboard, a wireless mouse, a 2-in-1 2.4G USB-A receiver, two AAA batteries for the keyboard, one AA battery for the mouse, a mouse pad, and a user manual. The dimensions of the product are 103.5mm x 64.2mm x 37.7mm. The battery compartment and USB receiver slot for the mouse are adjustable. The package also includes an After-Sales Email for customer support: jrkeyboard_cs@163.com.

Product Usage Instructions

1. Remove all items from the package.
2. Insert two AAA batteries into the keyboard's battery compartment.
3. Insert one AA battery into the mouse.
4. Place the mouse pad on a flat surface.
5. Connect the 2-in-1 2.4G USB-A receiver to a USB-A port on your device. If your device doesn't have a USB-A port, you will need a USB transfer adapter.
6. Find the Mouse USB Receiver Slot on the mouse and locate the built-in 2-in-1 USB-A nano receiver.
7. Power on your device and ensure that it is within the range of the wireless keyboard and mouse.
8. Use the wireless keyboard and mouse for your desired tasks.
9. If you encounter any problems during usage, please contact customer support via the provided After-Sales Email: jrkeyboard_cs@163.com.

Note: The keyboard and mouse use one 2.4G USB-A receiver at the same time. The 2-in-1 USB-A receiver is included in the mouse USB receiver slot. Make sure your device has a USB-A port for the receiver or use a USB transfer adapter.

Thank you very much for purchasing this Keyboard & Mouse Combo. Please read this user manual carefully to ensure it function correctly. Please contact us in time via After-Sales Email if you encounter any problems during using.

Package Contents

- 1 x Wireless Keyboard
- 1 x Wireless Mouse
- 1 x2-in-1 2.4G USB-A Receiver
(It was inserted in the Mouse USB Receiver Slot)
- 2 x AAA Batteries for Keybaord
- 1 x AA Battery for Mouse
- 1 x Mouse Pad
- 1 x User Manual

Specification


Keyboard K893G

Battery requirement	AAA batteries*2 Included in the package
Dimensions	453*157*27.3mm
Materials	ABS
Lifespan	Over 10,000,000 times strokes
Wireless range	8-10 meters
Working temperature	0-40℃
Working voltage	3.0V
Working current	10mA

Mouse M893G

Battery requirement	AA battery *1 Included in the package
Dimensions	103.5*64.2*37.7mm
Materials	ABS
Lifespan	Over 20,000,000 times clicks
DPI	800/1200/1600 Adjustable
Wireless range	8-10 meters
Working temperature	5-50℃
Working voltage	1.9V-3.3V
Working current	5mA

Product Layout



Note:

- The keyboard and Mouse use one 2.4G USB-A Receiver at the same time;
- The 2-in-1 USB-A Receiver was included in the mouse USB receiver Slot;
- Please make sure your device has a usb-a port for the receiver, or you need a usb transfer adapter.

1. Num Lock Indicator: Stays red when num pad is unlocked.
2. Caps Lock Indicator: Stays red when caps lock is activated.
3. Power Indicator (keyboard): Turns red when the power goes out.
4. Battery Compartment (keyboard): Align 2 AAA batteries properly into the compartment according to their positive and negative terminals.
5. Keyboard USB Receiver Slot (alternative): This alternative USB receiver slot is for you to take your receiver with your keyboard. Note: it is empty when your product first arrives.
6. Battery Compartment (mouse): Open the lid of the battery compartment. Install an A battery properly into the compartment according to their positive and negative terminals.
7. Mouse USB Receiver Slot: A built-in 2-in-1 USB-A nano receiver can be found here when you use your keyboard for the first time.
8. Power Switch (mouse): To open the mouse, please pull the power switch to the 'ON' side.
9. DPI Button: This middle click is DPI button. Click the button once to adjust the DPI level (800/1200/1600). The default setting is 1200 DPI.

Keys & Functions

Key	Functions	Key	Functions
FN+F1	Music	FN+F7	Play/Pause
FN+F2	Volume-	FN+F8	Stop
FN+F3	Volume+	FN+F9	Home
FN+F4	Mute	FN+F10	Mail
FN+F5	Previous track	FN+F11	Files
FN+F6	Next track	FN+F12	Favorites

Note: Hotkeys are only available for Windows 7 and above. Other operating systems not be compatible with these hotkeys settings.

System Requirements

- Windows 7 and above
- Mac OS / iOS / Android (For typing only, Hotkeys not work)

Operating Steps

1. Take your keyboard & mouse combo out of the case.
2. Open the lid of the battery compartment. Align batteries properly into the compartment according to their positive and negative terminals. Install batteries into the keyboard & mouse.
3. Take the USB nano receiver out from the receiver slot on your mouse.
4. Plug the USB receiver into the USB port on your device. Press any key to start using the keyboard & mouse.

Features

1. The keyboard & mouse are both enabled with a plug-and-play USB nano receiver. It is stored in the receiver slot behind the mouse. Keeping this USB receiver inserted into your device will not cause any damage to it. You can also store the USB receiver inside the keyboard.
2. The keyboard & mouse will enter into sleep mode after not being used for 15 minutes to save energy. Any press or click will reactivate them. It is suggested that you take batteries out of your keyboard & mouse if they are not in use for a long time.

Safety Instructions

Warning: Fire, electric shock, damage to keyboard device could occur if the following instructions are not obeyed

Danger × Warning A Note

- Away from edge tool
- Away from microwave radiation source
- Do not place heavy objects on this product

- No shocking and bending
- Away from oil, chemical, or organic solvents


Troubleshooting Steps

When your keyboard & mouse combo cannot function correctly,

please check the following steps:

1. Check if batteries are out of power.
2. Check if batteries align correctly according to their negative and positive terminals in the battery compartment.
3. Check if the USB receiver is plugged into the USB port and the USB port works properly.
4. Keep the distance between the keyboard and mouse within 50 centimeters, then reinstall the batteries and click any key to activate the keyboard. Please complete these steps within 15 seconds.

Please contact us in time via After-Sales Email if you encounter any problems during using.



Federal Communications Commission Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


Warning: Changes or modifications made to this device not expressly approved by the party responsible for

compliance may void the FCC authorization to operate this device.
Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user’s authority to operate the equipment.

After-Sales Email: jrkeyboard_cs@163.com



Documents / Resources

	BOOGIIO B1dSwsN2JUL Wireless Keyboard and Mouse Combo [pdf] User Manual B1dSwsN2JUL Wireless Keyboard and Mouse Combo, B1dSwsN2JUL, Wireless Keyboard and Mouse Combo, Keyboard and Mouse Combo, Mouse Combo, Combo
---	--

References

- [User Manual](#)