

Boori V24 Tidy Learning Tower Instruction Manual

Home » Boori v24 Tidy Learning Tower Instruction Manual

Contents

- 1 Boori V24 Tidy Learning Tower
- 2 Specifications
- **3 Product Usage Instructions**
- 4 Hardware
- **5 Parts List**
- 6 Assembly
- **7 Kids Furniture Care**

Instructions

- 8 Warranty
- **9 CONTACT INFORMATION**
- 10 Documents / Resources
 - 10.1 References
- 11 Related Posts



Boori V24 Tidy Learning Tower



Specifications

• Product Name: Tidy Learning Tower

• Model Number: BK-TILETv24

• Main Materials: European Beech / Plywood

Product Usage Instructions

· Assembly:

- Do not tighten the bolts initially.
- $\circ\,$ Position the learning tower upright before tightening bolts to ensure it sits level on the ground.

• Cleaning and Maintenance:


- Follow these care instructions to keep your furniture looking its best:
 - **Product Positioning:** Avoid lifting or altering the positioning of the furniture.
 - Cleaning: Use appropriate cleaning methods for maintenance.
 - Maintenance: Regularly inspect and maintain the product as needed.

Tidy Learning Tower (BK-TILETv24)


• Dimensions (External): 536×526×900(mm)

• Main Materials: European Beech / Plywood

Hardware





Parts List




Assembly

• Do not tighten the bolts for now.





• Before tightening bolts, position the learning tower upright to ensure that it sits level on the ground.



Kids Furniture Care Instructions

We hope you love your new Boori Kids furniture and it becomes an important part of your family home. To keep your furniture looking its best, please follow these care instructions.

Assembly

- · When assembling your furniture, please follow the assembly instructions and use the tools supplied
- · Boori products should only be assembled by an adult away from children
- · Heavy components should be lifted by two people to prevent injury
- · Every section that is assembled should be checked after assembly before moving on to the next stage

Product Positioning

- This product is made of timber and is therefore flammable
- Do not place your Boori furniture near open flames, fireplaces or extreme heat sources such as electric or gas heaters
- Do not direct sprayers or humidifiers at the furniture as they can cause damage
- Where possible avoid exposing furniture to extreme changes in temperature. Timber is a natural product and will want to expand and contract as the temperature varies. Extreme temperature variations can damage timber products.
- Avoid direct exposure to sunlight as this can cause our natural timber and plant oil colors to fade.
- Black rubber feet on items such as radios, computers, and picture frames can cause marks. Always use a felt mat (not plastic) to protect your Boori furniture
- Do not place in damp environments or areas with high levels of moisture as this encourages mould growth.

Cleaning

- Clean your furniture by wiping it with a soft, damp cloth
- If necessary, use a mild soapy solution and wipe clean with a soft cloth
- · Do not use strong household cleaners
- Always wipe in the direction of the wood grain, not in circles.
- · Wipe up spills immediately with a soft cloth
- Protect the furniture against bedwetting as this can lead to discoloration

Maintenance

- · We advise that you regularly check the safety of your furniture
- Ensure all bolts and screws are tightened and check for loose connections, missing parts or sharp or pointed edges
- Avoid contact with sharp objects and hot liquids
- When moving furniture always lift and place it into position; do not drag. We recommend that two people lift or alter the positioning of the furniture

Product testing Standards

• Standard: GB 28007-2011

Warranty

Warranty Against Defects - Australia

This Boori Kids product ("Product") (including mattress) carries a full one (1) years manufacturer's warranty ("Warranty Period") to the end-purchaser ("the Customer") as a testimony to the quality and longevity of the product. This warranty excludes general wear & tear and damage caused, by the Product not being used by its instructions or the care instructions. During this Warranty Period, Boori Australia Pty Ltd (ABN 43 160 962 354) (Boori") will replace or repair any defective part. In the event of a Product being replaced, as a whole unit or part thereof during the Warranty Period, the warranty on the replacement will expire one (1) year from the original purchase date. This guarantee excludes accidental damage, misuse, and or improper transporting and handling. The warranty is void if the original Product has been altered in design or color in any way. Subject to the Australian Consumer Law, this Warranty does not apply to any products sold as seconds, floor stock, repaired products, or products that have a defect where this has been drawn to the customer's attention before the purchase of the product. In addition, this Warranty will not apply if:

- (a) Repairs to a product are made or attempted by a service provider other than one approved by Boori.
- **(b)** The product has not been used or maintained by the manufacturer's instructions as provided with the product.
- (c) The customer abnormally uses the product for example if the product is abused, misused, dropped, crushed, impacted with any hard surface, exposed to extreme heat (including fire) or cold, not maintained properly or used after partial failure.
- (d) The product has been modified, incorrectly adjusted, or operated, subjected to incorrect electrical supply or inconsistent electrical supply, or used with inappropriate accessories.
- (e) The product is tampered with in any way

All warranty claims must be lodged:

- 1. at the place of original purchase as set out on your receipt for purchase of the Products or you may contact Boori on 02 9833 3769 to obtain further details; and
- 2. together with proof of purchase.

Where the Customer claims under this Warranty, all expenses incurred in sending the Products to Boori are the Customer's responsibility. Boori's liability in respect of a breach of a consumer guarantee or any warranty made under this Warranty for any Products not of a kind ordinarily acquired for personal, domestic, or household use is limited, to the Products to the extent permissible by law and at it's option to:

- 1. replacing the Products or the supply of equivalent Products;
- 2. the repair of the Products;
- 3. the payment of the cost of replacing the Products or of acquiring equivalent goods; or
- 4. the payment of the cost of having the Products repaired.

To the extent permitted by law, all other warranties whether implied or otherwise, not set out in this Warranty are excluded and Boori is not liable in contract, tort (including, without limitation, negligence or breach of statutory duty) or otherwise to compensate the Customer for:

- 1. any increased costs or expenses;
- 2. any loss of profit, revenue, business, contracts, or anticipated savings;
- 3. any loss or expense resulting from a claim by a third party; or
- 4. any special, indirect, or consequential loss or damage of any nature whatsoever caused by the Customer's

failure to comply with its obligations.

Limitations on Warranty Disclaimers

- In the following paragraph, 'Our' means 'Boori', 'You' means 'the Customer', and 'goods' means 'Products':
- Our goods come with guarantees that cannot be excluded under the Australian Consumer Law.
- You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage.
- You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.
- The benefits given to the Customer in this Warranty are in addition to other rights and remedies under a law concerning the Products to which this warranty applies.
- All Boori products (including mattresses) carry a full one (1) years manufacturer's warranty as testimony to the quality and longevity of the range.
- This warranty excludes general wear & tear and damage caused, by the product not being used following its instructions or the care instructions.
- During this guarantee period, Boori will replace or repair any defective part. In the event of a product being replaced, as a whole unit or part thereof during the guarantee period, the guarantee on the replacement will expire one (1) year from the original purchase date.
- This guarantee excludes accidental damage, misuse, and or improper transporting and handling.
- The warranty is void if the original product has been altered in design or color in any way.
- All warranty claims must be lodged at the place of original purchase and proof of purchase must be provided to lodge a warranty claim.

IMPORTANT: PLEASE READ THE INSTRUCTIONS CAREFULLY AND KEEP FOR FUTURE REFERENCE

CONTACT INFORMATION

- Boori Australia Pty Ltd
- 11/4 Southridge Street
- Eastern Creek NSW 2766
- Tel: +61 2 9833 3769
- www.boori.com.au
- Boori (Europe) Ltd
- Unit 1 Riverside House,
- Mill Lane, Newbury,
- Berkshire, RG14 5QS UK
- Tel: +44 016 3529 5670
- www.boori.co.uk

Documents / Resources



<u>Boori V24 Tidy Learning Tower</u> [pdf] Instruction Manual V24 Tidy Learning Tower, V24, Tidy Learning Tower, Learning Tower, Tower

References

- Boori UK | Baby Nursery & Kids Furniture
- O Boori International
- 8 Furniture Online | Nursery, Kids & Grown-Ups Online Furniture Store Boori Australia
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.