




BOOX Note Air3 C Tablet User Guide

[Home](#) » [BOOX](#) » BOOX Note Air3 C Tablet User Guide 

BOOX Note Air3 C Tablet User Guide

BOOX Note Air3 C
Quick Start Guide

For further instructions, please learn from the pre-loaded User Manual or official website technical support
www.boox.com



FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.

1. Power button
2. USB-C port
3. Mic
4. Dual Speakers
5. MicroSD card slot

- a. BOOX Device
- b. Warranty Card
- c. Quick Start Guide
- d. Stylus Pen
- e. USB-C Cable

Contents

[1 QUICK START GUIDE](#)


[2 Documents / Resources](#)

QUICK START GUIDE

Turn on the device: Hold down the power button for 2-3 seconds.

Charging: When the battery is low or the device can not be turned on, please connect your BOOX with a PC or an Adaptor to charge it, When the device is the indicator turns blue.

Firmware update: OTA update on the device. To force shutdown, please hold the power button for about 15 seconds. You can read the full version of the User Manual in the Settings menu of the device.



BOOX

customer support center:


<https://www.boox.com/support/>

Email: help@boox.com

Made in China

@Onyx International Inc. All rights reserved.

Documents / Resources

	BOOX Note Air3 C Tablet [pdf] User Guide XR3-AIR3C, XR3AIR3C, air3c, Note Air3 C, Note Air3 C Tablet, Tablet
---	--