



BOOX Poke4 Lite eReader Tablet User Guide

Home » BOOX » BOOX Poke4 Lite eReader Tablet User Guide 🖺



Poke4 Quick Start Guide

For further instructions, please learn from the pre-loaded User Manual or official website technical support. www.boox.com





- 1. Power
- 2. Microphone
- 3. USB-C Port
- a. BOOX Device
- b. Warranty Card
- c. Quick Start Guided. USB-C Cable

Contents

- 1 QUICK START GUIDE
- 2 Documents /

Resources

- 2.1 References
- 3 Related Posts


QUICK START GUIDE

Turn on the device:

Hold down the power button for 2-3 seconds.

Charging: When the battery is low or the device can not be turned on, please connect your BOOX with a PC or an Adaptor to charge it. When the device is charging, the indicator shows red. When the battery is fully charged, the indicator turns blue.

Firmware update: Download the update packages to the root directory of the local storage, or get OTA updates on the device. To force shutdown, please hold the power button for about 8 seconds. You can read the full version of the User Manual on the official BOOX website: https://www.boox.com/downloads/





Customer support center:

https://www.boox.com/support/

Email: help@boox.com Made In China

COnyx International Inc. All rights reserved.











Documents / Resources

BOOX Poke4 Lite eReader Tablet [pdf] User Guide POKE4, XR3-POKE4, XR3POKE4, Lite eReader Tablet, Poke4 Lite eReader Tablet

References

- " Home | The Official BOOX Site
- Home | The Official BOOX Site
- ** Home | The Official BOOX Site
- Home | The Official BOOX Site
- Home | The Official BOOX Site

Manuals+,