



## **BOSCH CTL636ES6 Built In Fully Automatic Coffee Machine Instruction Manual**

[Home](#) » [Bosch](#) » **BOSCH CTL636ES6 Built In Fully Automatic Coffee Machine Instruction Manual** 

**BOSCH CTL636ES6 Built In Fully Automatic Coffee Machine**



## Contents

- [1 Dear Coffee Connoisseur,](#)
- [2 Important notes](#)
- [3 Customer Support](#)
- [4 Documents / Resources](#)
  - [4.1 References](#)
- [5 Related Posts](#)


### Dear Coffee Connoisseur,

when you are preparing a flavoursome coffee drink, the water you use plays an important role. After all, it accounts for about 98% of a cup of coffee.

That is why we recommend you use the BRITA INTENZA water filter cartridge, which is designed specially for use with your appliance. It allows the flavour to develop optimally and also gives your appliance maximum protection from limescale.



As the calcium content of water has a significant influence on the aroma and the ,creme of your coffee, the BRITA INTENZA water filter cartridge has an aroma ring on the underside. By turning this ring you can set the optimal aroma level (A, B or C) for your tap water.




Please use the enclosed test strip to ascertain the optimal setting of the aroma ring.


1. Dip the test strip in the tap water for 10 seconds then wait for about 1 minute before checking the result.
2. Now compare the water hardness levels:
  - ☐ Levels 1 and 2– ring setting A
  - ☐ Level 3 – ring setting B
  - ☐ Level 4 – ring setting C
3. Record the test results for future filter changes by ticking the appropriate box.

**The BRITA INTENZA water filter cartridge is easy to use. Just proceed as follows:**


Turn the aroma ring on the underside of the water filter cartridge to the correct level.



Hold the water filter cartridge under cold water and gently agitate it to remove all the air bubbles.



Then place the filter cartridge firmly in the water tank by hand (or using the measuring spoon if you have it nearby).



Now remove the water tank and fill it with cold water up to the “max” mark.



As the calcium content of water has a significant influence on the aroma and the ,crema‘ of your coffee, the BRITA INTENZA water filter cartridge has an aroma ring on the underside. By turning this ring you can set the optimal aroma level (A, B or C) for your tap water.

**Important:** The BRITA INTENZA water filter cartridge must be rinsed in water before the first coffee or espresso is dispensed. Please read how to do this in the instructions. When the display indicates it is time to change the water filter, or at the latest after 2 months, the cartridge is no longer effective. Please replace the BRITA INTENZA water filter cartridge for reasons of hygiene and so that there is no build-up of limescale (this could damage the appliance). Each time you change the cartridge, be sure to repeat the steps described above.

Dispose of the used filter cartridge in accordance with local regulations. If you have more questions, contact BRITA Consumer Service at 0844742 4800.

Replacement cartridges are available from retail outlets or from our customer service.

**Important:** Please be sure to read the water filter section in the instructions so that you are familiar with the exact settings for your appliance.

The filter cartridge must be removed before one of the service programs (e.g. “Cleaning” or “Descaling”) is started.

## Important notes

- Replacement filter cartridges should always be stored in a cool, dry place in their original sealed packaging.
- The BRITA INTENZA water filter cartridge may only be used with tap water provided by water utilities. This drinking water is constantly checked and meets the legal requirements governing drinking water quality. If users are advised by the official authorities to boil their tap water, BRITA filtered water should also be boiled. When the 'boil water' notice has been lifted, the fully automatic espresso machine should be cleaned completely and a new filter cartridge inserted.
- Filter cold water only.
- Clean the water tank regularly.
- Remember that it is generally advisable to boil tap water for certain groups of people (e.g. those with weak immune systems). This also applies to filtered water.
- Note for dialysis patients or those with kidney disease: During the filter procedure there may be a slight increase in potassium content. If you have kidney disease and/or have to keep to a special potassium diet, we recommend you consult your doctor first.
- If your fully automatic espresso machine has not been used for a prolonged period (for example if you have been on holiday), we advise you to pour out any unfiltered water that is still present and to leave the filter cartridge in the water tank. Before you use the fully automatic espresso machine again, remove the water filter cartridge from the water tank, clean it and repeat the steps for rinsing the filter cartridge as described in the instructions.
- Water should be regarded as another food product. Please use up water in the tank within 1 day.
- Please understand that we cannot accept any liability or guarantee if you fail to observe our recommendations on the use and changing of BRITA INTENZA water filter cartridges.

## Customer Support


BSH Hausgeräte GmbH  
Carl-Wery-Straße 34,  
81739 München, GERMANY  
A Bosch Company  
[www.bosch-home.com](http://www.bosch-home.com)

Valid within Great Britain:  
Imported to Great Britain by  
BSH Home Appliances Ltd.  
Grand Union House  
Old Wolverton Road  
Wolverton, Milton Keynes  
MK12 5PT, United Kingdom



**BOSCH**

Documents / Resources

	<p><a href="#">BOSCH CTL636ES6 Built In Fully Automatic Coffee Machine</a> [pdf] Instruction Manual CTL636ES6 Built In Fully Automatic Coffee Machine, CTL636ES6, Built In Fully Automatic Coffee Machine, Automatic Coffee Machine, Coffee Machine, Machine</p>
---	--

References

- [🏠 Home Appliances Global Website | Bosch](#)