



BOSE 857000-0110 Sub1 Sub2 Adjustable Speaker Pole User Manual

[Home](#) » [Bose](#) » BOSE 857000-0110 Sub1 Sub2 Adjustable Speaker Pole User Manual 

Contents

- [1 BOSE 857000-0110 Sub1 Sub2 Adjustable Speaker Pole](#)
- [2 Product Information:](#)
- [3 Important Safety Instructions:](#)
- [4 Regulatory Information:](#)
- [5 Warranty Information:](#)
- [6 Product Usage Instructions:](#)
- [7 Assmebly](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)



BOSE 857000-0110 Sub1 Sub2 Adjustable Speaker Pole



Product Information:

The Adjustable Speaker Pole is a product designed to support and elevate a loudspeaker, particularly the Bose S1 Pro, using a Sub2/Sub1 configuration with an M20 thread. The pole can be adjusted to various heights and is compatible with other loudspeakers that have a 35mm pole socket.

The product weighs 1.54kg and has dimensions of (H x W x D) 3.40 x 1.54 inches. It is manufactured by Bose Electronics (Shanghai) Company Limited, Level 6, Tower D, No. 2337 Gudai Rd. Minhang District, Shanghai 201100.

Important Safety Instructions:

- Do not expose the loudspeaker or mounting components to any chemical substances that are not specified by Bose, as this can lead to degradation of the plastic material and create a falling hazard.
- The product contains small parts that may be a choking hazard and is not suitable for children under age 3.
- Do NOT make unauthorized alterations to this product.
- Only use attachments/accessories specified by the manufacturer.
- Do not place the product near any heat sources, such as fireplaces, radiators, heat registers or other apparatus (including amplifiers) that produce heat.
- This product is intended for indoor use only. Do not use this product outdoors or around water, mist, or condensation.
- Unsafe mounting of any heavy load can result in serious injury or death, and property damage.
- The pole-mount M20 threaded insert on the Sub1 and Sub2 is designed to support the Sub1/ Sub2 Adjustable Speaker Pole with a Bose S1 Pro mounted on the pole. Do not use the Sub1/Sub2 Adjustable Speaker Pole with a loudspeaker whose weight exceeds 7.1 kilograms (15.7 pounds). Doing so creates an unstable mounting scenario that may lead to a hazardous condition that could result in injury.
- Make sure the stage or ground is stable and level before placing a speaker on the pole.
- Once the subwoofer, pole and loudspeaker are attached, make sure the whole assembly is secure and does not present a tipping hazard or safety risk.
- Do NOT attempt to move the whole assembly (subwoofer, pole, and loudspeaker). Remove the loudspeaker from the pole before moving the subwoofer.

Regulatory Information:

The product complies with regulatory standards set forth by the manufacturer and is safe for use.

- **Dimensions:**

- Width: 9.0 cm (3.5 in)
- Depth: 6.7 cm (2.6 in)
- Height: 76.5–142.0 cm (30.1–55.9 in)

- **Net Weight:** 1.54 kg (3.40 lb)

China Importer: Bose Electronics (Shanghai) Company Limited, Level 6, Tower D, No. 2337 Gudai Rd. Minhang District, Shanghai 201100

- **UK Importer:** Bose Limited Bose House, Quayside Chatham Maritime, Chatham, Kent, ME4 4QZ, United Kingdom

- **EU Importer:** Bose Products B.V., Gorslaan 60, 1441 RG Purmerend, The Netherlands

- **Mexico Importer:** Bose de México, S. de R.L. de C.V., Paseo de las Palmas 405-204, Lomas de Chapultepec, 11000 México, D.F. For service or importer information, call +5255 (5202) 3545.

- **Taiwan Importer:** Bose Taiwan Branch, 9F-A1, No. 10, Section 3, Minsheng East Road, Taipei City 104, Taiwan. Phone Number: +886-2-2514 7676

Bose Corporation Headquarters: 1-877-230-5639

Bose is a trademark of Bose Corporation.

©2022 Bose Corporation. No part of this work may be reproduced, modified, distributed or otherwise used without prior written permission.

Warranty Information:


The Adjustable Speaker Pole is covered by a limited warranty from Bose. For more information on the warranty, visit global.bose.com/warranty.


Product Usage Instructions:

1. Attach the pole to the Sub2 or Sub1 loudspeaker using the M20 thread.
2. Adjust the height of the pole to the desired level.
3. Place the Sub2/Sub1 loudspeaker on the ground or on a stable surface.
4. Connect the loudspeaker to an audio source using an appropriate cable.
5. Power on the loudspeaker and adjust the volume as needed.


Assmebly



1






3







[BOSE 857000-0110 Sub1 Sub2 Adjustable Speaker Pole](#) [pdf] User Manual
857000-0110 Sub1 Sub2 Adjustable Speaker Pole, 857000-0110, Sub1 Sub2 Adjustable
Speaker Pole, Adjustable Speaker Pole, Speaker Pole, Pole

References

-  [Warranties | Bose](#)
-  [Bose Speakers, Headphones, and Soundbars for Unmatched Audio Quality](#)

[Manuals+](#).