

BOUNTECH OP3799 Inflatable Bouncer User Manual


[Home](#) » [BOUNTECH](#) » BOUNTECH OP3799 Inflatable Bouncer User Manual 

Contents

- [1 BOUNTECH OP3799 Inflatable Bouncer](#)
- [2 Before You Start](#)
- [3 SAFETY WARNINGS: SET UP](#)
- [4 SAFETY WARNINGS](#)
- [5 Staking the Bouncer](#)
- [6 Part List](#)
- [7 Minimum Clearance ZonesS](#)
- [8 Bouncer Placement](#)
- [9 Set Up](#)
- [10 INFLATION & STAKING](#)
- [11 STORAGE](#)
- [12 REPAIR PATCH INSTRUCTIONS](#)
- [13 INSTRUCTIONS FOR WATER PARK MAINTENANCE](#)
- [14 DISPOSAL](#)
- [15 Documents / Resources](#)
- [16 Related Posts](#)



BOUNTECH OP3799 Inflatable Bouncer



Before You Start

Please read all instructions carefully and keep it for future reference.

Warnings:

- **Attention:** For home use only.
- **Attention:** The Product is not suitable for the children under 3 years
- **Danger:** Keep all small parts and packaging materials for this product away from babies and children, otherwise they may pose a choking hazard.
- **Danger:** Lack of attachment may cause a risk of tipping or fall hazards.

General Warnings:

- The product must be installed and used under the supervision of an adult.
- Read through each step carefully and follow the proper order.
- Remove all packaging, separate and count all parts and hardware.
- Please ensure that all parts are correctly installed, incorrect installation can lead to a danger.
- We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- Ensure a secure surface during construction, and place the product always on a flat, steady and stable surface.
- Please check and maintain regularly, the most important parts for suspension, fixing, anchoring to the ground.

SAFETY WARNINGS: SET UP

ADULT SUPERVISION AND SET UP REQUIRED. This product should be inflated or deflated only by a competent adult. Follow all instructions provided.

WARNING! Falls onto hard surfaces can result in head or other serious injuries. Never place on concrete, asphalt, wood, packed earth, or other hard surfaces. Carpet over hard floors may not prevent injury

- Product is heavy. Use caution when lifting.
- Product should never be dragged across concrete, pavement or other rough surfaces.
- **WARNING!** Keep away from fire. Keep fabric clear of all flame and ignition sources.
- Do not set up in windy or rainy conditions: sudden gusts of wind may lift the product off the ground.
- Product can be installed in any orientation in relation to the sun, since there are no metal components or surfaces that can absorb excessive solar radiation.
- Set-up in outdoor location only that meets the following criteria
 - Place on level ground and firm grass or soil to allow proper use of stakes.
 - Placing on slanted or uneven surfaces may cause the product to tip.
 - Stakes should be placed at an angle for better anchorage, should be driven under the ground to prevent tripping.
 - Minimum clearance zones: Place at least 2m away from any other objects.
 - Objects to be avoided include but are not limited to fences, buildings, trees, overhead\ branches, laundry lines, electrical wires, walls, or bodies or sources of water.
 - Make sure the area around the product is secure by adding safety barriers, if necessary, to keep young children and pets from gaining access.
- Electrical cord must not be passed under the air filled devices (Inflatable Bouncer) and interfere with its operation. The Bouncer with Slide uses a main powered blower (air pump) to maintain pressure, only to be used by an adult.
- Do not use extension cords with this product. Set up as close to power source as possible.
- The blower should be securely anchored to the ground before use.
- **CAUTION:** the blower is capable of moving large volumes of air very quickly. Place the blower in an area where it will not draw in dirt or leaves. Keep blower and power cord away from children, water and traffic.
- **ATTENTION:** Blower should remain on and continuously inflate Bouncer during use. Airflow through seams is normal
- Do not use the product if wind speed exceeds 30Okm/h.
- Do not consume food, drink and gum on this product.

SAFETY WARNINGS


- Constant, competent adult supervision of children and other young users is required at all times.
- Keep the area around the product clean, and clear of objects, to prevent slips and falls.
- Do not allow children to play in the product until it is fully inflated.
- Do not allow children to play on if wet. Thoroughly dry before use.
- This is not an aquatic toy. It is not to be used in water.
- Instruct children on proper use of this product:
- Children should not wear loose or baggy clothing, scarves, hoods or clothing with drawstrings or long cords while playing on this product.
- Children must remove helmets, headgear, shoes and glasses, as well as any sharp objects from their pockets, as they may puncture the bouncing surface.
- Toys and other objects should never be allowed inside the bouncer.
- Instruct children not to attach items to the product that are not specifically designed for use with the equipment,

such as but not limited to, jump ropes, clothesline, pet leashes, cables and chains as they may cause a strangulation hazard.

- Keep pets away from product.
- Children should bounce away from others, and stay away from openings and side walls.
- Children should not jump onto or off the product.
- Total weight of children must not exceed 300 lbs. (135 kg)
- No more than 3 children should play on the Bouncer at the same time.
- Do not allow children to play together who are unevenly matched in weight and height.
- Before and during use, check for air loss. Check blower is properly Connected.
- Always check the product and all its anchorage points before and during use, and to re-secure as appropriate.
- After inflation, the blower should run continuously while children are playing.
- Prior to deflating, remove all children.
- Always deflate product after use, and store indoors.
- To be used on soft ground only.
- Users must be discouraged from attempting any unauthorized modification.
- The product should be periodically examined for potentially unsafe conditions such as: damaged cord, plug, housing, or parts, and that in the event such damage is found, the product should not be used until properly repaired. Never leave the fan outside in the rain or elements when not in use. Refer to the instructions for set-up, storage, maintenance and care.

Staking the Bouncer


CAUTIONS: The Bouncer and all its anchorage points should be checked before and during use. Reinflate or re-secure as appropriate. DO NOT let children play on the Bouncer until it is fully inflated!



CAUTIONS:

- Drive ground stakes completely into the ground to avoid tripping hazard.
- Do not set up or inflate the Bouncer with slide in windy and/or rainy conditions as wind gusts may cause the park to become unstable and possibly be lifted from the ground.

Part List



A). 1 Inflatable Bouncer
15.6' x 7.8' x 7' (188" x 94" x 84")
Approximate Size Inflated



B). 1 Carrying Bag



C). 4 Repair Patches



D). 7 Bouncer Stakes



E). 50 Ball pit




F). 1 PVC ball




G).3 Target balls

Minimum Clearance Zones

Make sure that there is a 2m (6.6ft) obstacle-free zone around the product, including a fence, garage, house, overhanging branches, laundry lines or electrical wires.



Bouncer Placement



Designate a flat, level surface that allows for 2m (6.6ft) of minimum clearance around the Bouncer.


NOTE: DO NOT place the Bouncer on a hard surface like asphalt, concrete or packed earth as both serious bodily injury and damage to the Bounce could result.

ASSEMBLY AREAS


Make sure the assembly area is flat and level and is free of rocks, sharp objects or other obstructions.

- Do not set up the Bounce on a slope or incline.
- Do not set up the Bounce on hard-packed earth, asphalt, decking or any hard surface as doing so may result in physical injury and/or damage to the Bouncer.
- Do not attempt to drag it to another location.
- Check your local county or city regulations for requirements on securing the pool.
- Secure the pool from unauthorized use.


Set Up



INFLATION & STAKING




STORAGE



REPAIR PATCH INSTRUCTIONS

WARNING: Repair patches must be applied by an adult only.

KEEP OUT OF REACH OF CHILDREN. INSTRUCTION:



1. Deflate the item, clean the area and allow to dry thoroughly.
2. Cut a portion of the patch to the size needed and round the corners. (See Fig).
3. Remove the adhesive backing from the patch material, position the patch over the damaged area and smooth out any bubbles.
4. Allow to sit for 30 minutes before re-inflating.

INSTRUCTIONS FOR WATER PARK MAINTENANCE


- As an outdoor product, the bouncer is subject to wear and deterioration. Inspect for signs of fabric failure; weak or torn surfaces must be repaired promptly.

- To keep the product clean: wipe the bouncer or blower using a dry cloth or a cloth dampened with a neutral, non-inflammable, nontoxic cleaning and sanitizing solution or pure water.
- Product should never be stored wet. Allow to dry before rolling up.

DISPOSAL

- Disassemble and dispose of the equipment in such a manner that no hazardous conditions exist at the time the equipment is discarded.
- Blower should be returned to a collection center

Documents / Resources

| | |
|---|---|
|  | <p>BOUNTECH OP3799 Inflatable Bouncer [pdf] User Manual OP3799, Inflatable Bouncer, OP3799 Inflatable Bouncer</p> |
|---|---|