Manuals+ — User Manuals Simplified.

brainboxes SW-0XX Ethernet Switch Range User Guide

brainboxes SW-0XX Ethernet Switch Range User Guide

Brainboxes Limited

18 Hurricane Drive,
Liverpool International
Business Park, Speke,
Liverpool, Merseyside,
L24 8RL,
United Kingdom

Brainboxes LLC
4600 140th Avenue North
Suite 180
Clear water
FL 33762
USA

Contents

Optional Accessory Items

Power Supply

PW-600 (UK/EU/US/AUS)

- Suitable for use with all SW products

DIN Rail Mounting Kit

MK-048

- Suitable for use with SW-005 & SW-015

USB Power Cable

PW-650 USB

- Suitable for use with all SW-5XX, SW-6XX & SW-7XX products

Switch products are also available for embedded applications.
This equipment is not suitable for use in locations where children are likely to be present

This product comes with Lifetime Warranty and Support

Full terms and conditions, as well as information on product accreditation, safety, and correct disposal of this product can be found on our website **www.brainboxes.com**.

More resources online www.brainboxes.com.

SW-0XX 3PIN
SW-1XX SW-5XX SW-7XX SW-7XXX
Dual Redundant Power Input
5PIN

SW-005, SW-505, SW-705, SW-104, SW-105: <1.35W @ +5VDC to +30VDC
SW-508, SW-708, SW-108, SW-008: <1.5W @ +5VDC to +30VDC

SW-515, SW-715, SW-115, SW-015, SW-514, SW-114: <3.6W @ +5VDC to +30VDC
SW-584, SW-084, SW-581: <4.2W @ +5VDC to +30VDC
SW-518, SW-718, SW-118: <6.5W @ +5VDC to +30VDC
SW-7016: <3.8W @ +5VDC to +30VDC
SW-7416: <6W @ +5VDC to +30VDC
SW-7617, SW-7717: <7.5W @ +5VDC to +30VDC

Power sources used with our products must be <100W

Documents / Resources

brainboxes SW-0XX Ethernet Switch Range [pdf] User Guide
SW-0XX, SW-0XX Ethernet Switch Range, Ethernet Switch Range, Switch Range, Range

References

- 🐾 **Homepage - Brainboxes**
- **User Manual**