



BRAUN BC21B Digital Alarm Clock with VA LCD Display User Guide

[Home](#) » [Braun](#) » BRAUN BC21B Digital Alarm Clock with VA LCD Display User Guide 

Contents

- [1 BRAUN BC21B Digital Alarm Clock with VA LCD Display](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Getting Started](#)
- [5 Using the alarm and snooze function](#)
- [6 Using the wireless charging function](#)
- [7 CONTACT](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)

BRAUN

BRAUN BC21B Digital Alarm Clock with VA LCD Display



Product Information

The BC21 Alarm clock with wireless fast-charging pad is a versatile and convenient device that combines an alarm clock with a wireless charging pad for Qi compatible devices. It features a sleek design and is equipped with various functions to enhance your experience.

- Product Name: BC21 Alarm clock with wireless fast-charging pad
- Model Number: BC21
- Manufacturer: Braun

Note: Certain trademarks used in this product are licensed from the Procter & Gamble Company or its affiliates.


Product Usage Instructions

Getting Started

1. Remove the battery door **(5)**.
2. Take out the button cell battery and remove the plastic strip.
3. Replace the button cell battery.
4. Close the battery door.
5. If using an AC/DC adapter to power the clock, plug the adapter into the USB-C jack at the back of the clock **(6)**.
6. Only use new alkaline batteries from a reputable brand.

Getting Started


1. Remove the battery door **(5)**.
2. Take out button cell battery and remove the plastic strip.
3. Replace the button cell battery.
4. Close the battery door.
5. An AC/DC adapter is being used to power the clock, plug the adapter into the USB-C jack at the back of the clock. **(6)**.



Only use new alkaline batteries from a reputable brand.


Setting the time

1. Slide the “ALARM / TIME / 12/24 HOUR / BRIGHTNESS” switch **(7)** to the TIME position.
2. Press the “+” or “-” key **(4)** to set the desired value. Press and hold to speed up the setting.
3. Slide the “ALARM / TIME / 12/24 HOUR / BRIGHTNESS” switch to the “BRIGHTNESS” position to return to normal display and save the setting.



Using the alarm and snooze function

1. Activate the alarm by pressing the “ALARM ON/OFF” button **(2)**. The bell icon will appear on the LCD display.
2. Press the SNOOZE zone **(1)** to stop the alarm and activate the snooze function. When the alarm sounds, the alarm icon will flash.
3. To de-activate the alarm and snooze function, press the ALARM ON/OFF button. The bell icon will disappear.



Using the wireless charging function

- Place your Qi compatible device on the centre of the wireless charging pad **(3)**. The charging icon will appear on the LCD display when the device is charging.

For detailed information refer to the full user manual available at www.braun-clocks.com/pages/warranty. or scan this code:




CONTACT




Braun helpline

- Should you have a problem with your product, please check your local service centre at: www.braun-clocks.com.
- www.braun-watches.com.
- Certain trademarks used under license from the
- Procter & Gamble Company or its affiliates.

Documents / Resources

	<p>BRAUN BC21B Digital Alarm Clock with VA LCD Display [pdf] User Guide</p> <p>BC21B Digital Alarm Clock with VA LCD Display, BC21B, Digital Alarm Clock with VA LCD Display, Alarm Clock with VA LCD Display, Clock with VA LCD Display, VA LCD Display, LCD Display</p>
---	--

References

-  [Braun-Clocks: Braun Shop online | Buy Braun Clocks & Watches](#)
-  [Warranty – Braun Clocks](#)
-  [Emit Collection | Buy Online Watches & Accessories Store](#)
- [User Manual](#)