

BRAUN BC22B Alarm Clock User Guide

Home » Braun » BRAUN BC22B Alarm Clock User Guide Ta




Contents

- 1 PRODUCT OWERVEV
- 2 Documents /
- Resources
 - 2.1 References
- **3 Related Posts**

PRODUCT OWERVEV

Battery installation

- 1. Remove the battery cover.
- 2. Insert 3xAA (1.5V) battery observing the correct polarity, as shown on the diagram.
- 3. Replace battery cover.



Only use new alkaline batteries from a reputable brand.

Time setting


Turn the time set knob () on the back of the clock in the direction of the arrow until the correct time is shown.

Alarm setting

Turn the alarm set knob () on the back of the clock in the direction of the arrow until the desired alarm time is shown.


Alarm function

To set the alarm, move the slider on the right side of the clock upwards. The alarm is set when the green color indicator is visible. To unset the alarm, move the slider on the right side of the clock downwards.



Snooze function

When the alarm is sounding, push the button at the top of the clock and the SNOOZE/LIGHT function will be activated. The alarm will be stopped and will sound again after ~5 minutes.



Backlight function

Anytime, push the button at the top of the clock and the backlight function will be activated. The dial will be illuminated for ~5 seconds.

For detailed information refer to the full user manual available at www.braun-clocks.com/pages/warranty or scan this code:



Braun helpline

Should you have a problem with your product, please check your local service center at:

www.braun-clocks.com www.braun-watches.com

Certain trademarks used under license from the Procter & Gamble Company or its affiliates.



Documents / Resources



BRAUN BC22B Alarm Clock [pdf] User Guide BC22B, BC22B Alarm Clock, Alarm Clock, Clock

References

- Braun-Clocks: Braun Shop online | Buy Braun Clocks & Watches
- Warranty Braun Clocks
- O Emit Collection | Buy Online Watches & Accessories Store
- User Manual

Manuals+,