



BRIGADE BL-2120C AHD Front Camera Monitor System User Manual

[Home](#) » [BRiGADE](#) » BRIGADE BL-2120C AHD Front Camera Monitor System User Manual 

BRIGADE[®]
VAN

BL-2120C AHD Front Camera Monitor System
User Manual



Adjusting the Angle of view

Contents

- [1 BL-2120C AHD Front Camera Monitor System](#)
- [2 Documents / Resources](#)
 - [2.1 References](#)

BL-2120C AHD Front Camera Monitor System

Please refer to <https://brigade-electronics.com/product-support-area/> for more information and technical documents

Step 1

Remove the back case from the camera with a Philips head screwdriver to reveal the sliding arm.



Step 2

Loosen the sliding mechanism using the Philips head screwdriver.



Step 3


This will now allow the lens to slide up and down to find the desired viewing angle. Once the camera has been adjusted to the desired angle, tighten the screw on the sliding mechanism, then replace cover and fixing screw.

**BRIGADE[®]
VAN**

technical@brigade-electronics.com

www.brigade-electronics.com

Documents / Resources

	<p>BRIGADE BL-2120C AHD Front Camera Monitor System [pdf] User Manual BL-2120C AHD Front Camera Monitor System, BL-2120C, AHD Front Camera Monitor System, Front Camera Monitor System, Camera Monitor System, Monitor System</p>
---	---

References

- electronics.com
- [Brigade Electronics | Commercial Vehicle Camera Systems](#)
- [Brigade Electronics | Commercial Vehicle Camera Systems](#)
- [Product Support Area | FAQs | Brigade Electronics](#)

