



brinno Time Lapse Camera TLC2020 / TLC2000 Firmware Upgrade Instructions

[Home](#) » [brinno](#) » brinno Time Lapse Camera TLC2020 / TLC2000 Firmware Upgrade Instructions 




Firmware Upgrade Procedure Time Lapse Camera TLC2020 / TLC2000 version EN A6

Contents

- [1 Prepare items](#)
- [2 Copy FW File to the microSD card](#)
- [3 Note:](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

Prepare items



*We recommend that the microSD card that came with the camera be used for all firmware updates. If you are using a new SD card that is over 32GB it will need to be formatted by your camera before it can be used. To format a new SD card, insert the card into your camera and follow the formatting prompts on the LCD screen before you start the firmware upgrade process.

Video Tutorial

A video tutorial of the firmware upgrade procedure can be found here: www.youtube.com/watch?v=4t7YbGTouyU




Copy FW File to the microSD card



MUST DOWNLOAD FIRMWARE WITH WINDOWS ONLY (NOT COMPATIBLE WITH MAC)

1. Power off the camera.
2. Install fully-charged batteries.
3. Take out a microSD card and insert it to a PC (Windows).
4. Download firmware zip file from: www.brinno.com/support/support-center/TLC2020
5. Right-click zip file and click <extract all> to access firmware file.
6. Open folder and ONLY copy the TLC2K_C.RCF file to microSD card in the 100TLC2K folder(F: DCIM/100TLC2K).

The 100TLC2K folder can be accessed through the DCIM folder.



- Start FW upgrade

7. Insert the microSD card into the camera.
8. Connect the camera to external power using the USB-C cable.
9. The camera will automatically turn on and upgrade firmware. The LED indicator will flash orange while firmware is upgrading.
10. When the upgrade is completed the camera will beep twice and restart automatically. The LCD screen will turn on when the upgrade is finished.


Note:

1. The firmware upgrade process is expected to be less than 10 minutes.
2. If the Orange LED flashes longer than 10 minutes, it means the upgrade was not successful. Follow the below steps:
 - a. Disconnect the external power and remove the batteries from the camera.
 - b. Format the microSD card on PC (Windows) one more time.

- c. Copy firmware file (TLC2K_C.RCF) to (TLC2K_C.RCF) into the microSD card F:\DCIM\100TLC2K).
- d. Make sure you follow the instructions closely. Please write to our Customer Service if you have further questions.

Supports: customerservice@brinno.com
www.brinno.com

Documents / Resources



Firmware Upgrade Procedure
Time Lapse Camera TLC2020 / TLC2000

[brinno Time Lapse Camera TLC2020 / TLC2000 Firmware Upgrade](#) [pdf] Instructions
brinno, Time, Lapse, Camera, TLC2020, TLC2000, Firmware, Upgrade