



Briopaws Smokeless FirePit with Stand User Guide

[Home](#) » [Briopaws](#) » Briopaws Smokeless FirePit with Stand User Guide 

Contents

- [1 Briopaws Smokeless FirePit with Stand](#)
- [2 Product Usage Instructions](#)
- [3 Helpful Tips](#)
- [4 FAQ](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)

Briopaws

Briopaws Smokeless FirePit with Stand




Specifications

- **Product Name:** Briopaws Smokeless Stove
- **Model Number:** [insert model number]
- **Material:** [insert material]
- **Dimensions:** [insert dimensions]
- **Weight:** [insert weight]

Product Usage Instructions

Position The Base On The Stand

Place the base of the stove on a stable surface or stand to ensure stability during use.




Insert The Stove Body Into The Base

Align the stove body with the base and firmly insert it until it is securely in place.




Place The Mesh Pot Inside The Stove

Take the mesh pot and place it inside the stove, ensuring it sits securely on the base.




Place The Lid

Put the lid on top of the stove to cover the mesh pot and create a closed cooking environment.



Light A Fire Inside The Stove

Using dry firewood or charcoal, light a fire inside the stove. Follow proper fire safety precautions and never leave a burning stove unattended.




Enjoy The Warmth Of The Fire

Once the fire is burning, you can enjoy the warmth it provides.




Wait For The Stove To Cool Down

After use, allow the stove to cool down completely before proceeding to the next steps.




Lift The Base To Pour Out The Ash

Carefully lift the base of the stove to access the ash accumulated at the bottom. Dispose of the ash properly.




Clean & Pack

Thoroughly clean the stove, removing any remaining ash or debris. Ensure it is dry before packing it away for storage or transportation.



Take It With You

The Briopaws Smokeless Stove is portable, so you can easily take it with you on your outdoor adventures.




Contact Us

If you have any issues or questions regarding the Briopaws Smokeless Stove, feel free to contact us at briopaws_service@hotmail.com.

Instagram

Follow us on Instagram for more tips and inspiration on using the Briopaws Smokeless Stove.



Helpful Tips

- Place the stove on a stable surface to prevent accidents.
- Use dry firewood or charcoal for optimal performance.
- Allow the wood to burn completely down to ashes before cleaning or storing the stove.
- Never leave a burning stove unattended.
- Keep the stove away from flammable materials to avoid fire hazards.
- Make sure to dry the stove thoroughly after cleaning to prevent rust or damage.

FAQ

1. Q: Can I use the Briopaws Smokeless Stove indoors?

A: The Briopaws Smokeless Stove is designed for outdoor use only. It should not be used indoors due to safety concerns.

2. Q: How do I clean the stove?

A: To clean the stove, wait for it to cool down completely. Then, remove the ash and debris from the bottom and wipe it clean with a damp cloth. Ensure it is completely dry before storing or using it again.

3. **Q: Can I use the stove with wet firewood?**

A: It is recommended to use dry firewood or charcoal for optimal performance. Wet firewood may produce more smoke and affect the stove’s efficiency.



Documents / Resources

[Briopaws Smokeless FirePit with Stand](#) [pdf] User Guide
Smokeless FirePit with Stand, Smokeless, FirePit with Stand, with Stand

References

- [User Manual](#)