



BroadLink Wi-Fi Smart Remote Hub with Sensor Cable User Manual

[Home](#) » [BroadLink](#) » BroadLink Wi-Fi Smart Remote Hub with Sensor Cable User Manual 

Contents

- [1 BroadLink Wi-Fi Smart Remote Hub with Sensor Cable](#)
- [2 IR And RF Appliance, Full Integration](#)
- [3 Voice Control](#)
- [4 APP Remote Control](#)
- [5 Temperature & Humidity Sensor](#)
- [6 Schedule Control](#)
- [7 Documents / Resources](#)



BroadLink Wi-Fi Smart Remote Hub with Sensor Cable



IR And RF Appliance, Full Integration

such as TVs, set-top boxes, and RF curtain



Voice Control

Works with Alexa and Google Assistant to add voice control to your IR appliances




APP Remote Control


Turn on your air conditioner on your way home

APP Remote Control

Turn on your air conditioner on your way home



Download BroadLink APP
In APP Store/Google Play



Temperature & Humidity Sensor

Eg. turn on the humidifier automatically when the humidity is dropped to 60%



Schedule Control

Individually schedule each smart plug to automatically turn on/off at set times





[BroadLink Wi-Fi Smart Remote Hub with Sensor Cable](#) [pdf] User Manual
Wi-Fi Smart Remote Hub with Sensor Cable, Wi-Fi, Smart Remote Hub with Sensor Cable, Hub with Sensor Cable, Sensor Cable