


bsi Pull-Out Base Unit Instruction Manual

Home » bsi » bsi Pull-Out Base Unit Instruction Manual

```
Contents

1 150 Pull-Out Base Unit
Assembly
2 Components
3 1 2 Assembly Instructions
4 4
5 5–6
6 7–9
7 10-11
8 13-14 Installation Instructions
9 15-16
10 17-19
11 20
12 Documents / Resources
13 Related Posts
```


150 Pull-Out Base Unit Assembly



TH Note: If fitting a "True Handleless" kitchen, some components will differ to those shown in this instruction and will also be packaged separately. Please refer to your True Handleless guide to Receiving for further details on the

different components and difference in installation.

Components



Important Information - True Handleless Kitchens Installers: See Note Above TH

Caution: Some pieces of hardware could be hazardous to small children. Keep all these items out of reach and do not leave children unattended in the assembly area. Please read these instructions carefully before proceeding. Refer to the Guide to Receiving and Installing your Kitchen booklet for further information. Note: Due to variation in wall conditions no screws are supplied for fixing the units to the wall. If in doubt consult an expert. Assemble the unit on a clean solid work surface. In the interest of continuing improvements we reserve the right to amend or adjust the specifications without prior notice. Errors and omissions excepted. This unit is fitted with a wirework system. The wirework is supplied separately. These instructions advise when to fit parts of the wirework system. Follow the instructions supplied with the wirework for wirework assembly. Every effort has been made to ensure that this product leaves the factory in perfect condition. In the unlikely event that an item is damaged or incorrect, please contact the customer services department.

Note – Fitting Handles: (1) Decide where you are going to position each handle to maintain symmetry around your kitchen. (2) Measure the handle centres and mark off each door/drawer position. (3) Drill through the door/drawer using a fine drill (<2.5mm), then drill back from the rear face using a 4.5mm drill. (4) Attach with the fixings provided with your handle.

Ref. No.	Item	Quantity
150101	3.5x12mm	4
150202	4x12mm	4
150201	4×15mm	16
150199	4.5x45mm	2
154082		8
154085		8

154004		8	
150308	1	2	
150309		2	
154047	To all	2	
151500		2	
151999		4	
152401		4	
152418		4	
152402		2	
Note: These are supplied with the wirework.			
	4.5x15mm	6	
	4.5x13mm	8	


Tools Required

5mm	Drill
	Medium Crosshead Screwdriver
	Large Flathead Screwdriver
	Spirit Level
	G-Clamp (pair)
	Hammer
The state of the s	Tape Measure
	Bradawl


1 2 Assembly Instructions

Note: These instructions show a right hand fixing. Mirror for a left hand fixing. It is advisable to fit the wirework

runners at this point. See wirework instructions for further details.




TH Modification required at this stage, see True Handle-less guide for further details.




4


TH Modification required at this stage, see True Handleless guide for further details.





5-6




Do Not Over Tighten Start Locked









10-11








Note: It is advisable to fit the frame to the runners at this point. See wirework instructions for further details.

13-14 Installation Instructions











17-19



20



Documents / Resources



bsi Pull-Out Base Unit [pdf] Instruction Manual Pull-Out Base Unit, 150

Manuals+,