

BTF-LIGHTING LET634 RGB LED Controller Strip Light Instruction Manual

Home » BTF-LIGHTING » BTF-LIGHTING LET634 RGB LED Controller Strip Light Instruction Manual



BTF-LIGHTING LET634 RGB LED Controller Strip Light Instruction Manual

RGB LED Controller Instrustions


You can use the switch or remote to control the lighting effects.

Contents


- 1 Description of switch function
- 2 Remote control instructions
- 3 Documents / Resources
 - 3.1 References

Description of switch function

- 1. Power on off-Press and hold the power button.
- 2. Change the mode: Short press the cycle button. (Multiple mode options: Static Red/Static Green/Static Blue/Static White/Multicolour Change/Multicolour Flash/Multicolour Breathing/White Breathing/Red Breathing/Green Breathing/Blue Breathing)
- 3. Adjust the flashing speed: Short press the power button.
- 4. Adjust the brightness Press and hold the cycle button and short press the power button meanwhile.



Remote control instructions



NOTE

- 1. During use, if the switch can work normally, but the remote control cannot, you need to perform the code matching operation.
- 2. if the light is interfered by other remote controls or cannot be controlled remotely. Please power off and then power on again before performing code matching. How to perform code matching operation: Press and hold the start button on the remote control for 3 seconds within 7seconds of turning on the power, the light strip flashes 3 times with white light, indicating that the code (remote control) is matched.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help. FCC Caution: Any changes or modifications not expressly approved by the party responsible for

compliance could void the user's authority to operate the equipment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.



Documents / Resources



BTF-LIGHTING LET634 RGB LED Controller Strip Light [pdf] Instruction Manual LET634 RGB LED Controller Strip Light, LET634, RGB LED Controller Strip Light, Controller Strip Light, Strip Light, Light

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.