




# BUD LIGHT MIS137BULT-6COM 6 Can Mini Retro Beverage Fridge Owner's Manual

[Home](#) » [Bud Light](#) » BUD LIGHT MIS137BULT-6COM 6 Can Mini Retro Beverage Fridge Owner's Manual 

## Contents

- [1 BUD LIGHT MIS137BULT-6COM Mini Beverage Refrigerator Owner's Manual](#)
  - [1.1 FEATURES](#)
  - [1.2 MODE SELECTION](#)
  - [1.3 MAINTENANCE](#)
  - [1.4 IMPORTANT NOTICE](#)
- [2 Documents / Resources](#)
  - [2.1 References](#)
- [3 Related Posts](#)

**BUD LIGHT MIS137BULT-6COM Mini Beverage Refrigerator Owner's Manual**

**BUD  
LIGHT®**



**Please Read These Instructions Carefully Before Use!**

**2022 ANHEUSER-BUSCH, LLC. BUD LIGHT® IS A REGISTERED TRADEMARK OF ANHEUSER-BUSCH, USED UNDER LICENSE.**

## **FEATURES**

This thermoelectric refrigerator is freestanding design. You must leave sufficient room on all four sides in order for the cooler to exhaust properly. If heat is not allowed to exhaust properly, the cooler will not operate efficiently. Moreover, due to the design of thermoelectric units, they should not be placed in a warm room. Typically it will cool anywhere between 20-28 °F below the ambient temperature but this depends on many environmental factors.

<b>SPECIFICATIONS</b>	
POWER RATING AC	120V, 60Hz, 50W
POWER RATING DC	12V, 3.5A, 42W
CAPACITY	6CANS
DIMENSIONS	6.8"W x 9.7"D x 9.5"H
MODEL	MIS137BULT-6COM

## **MODE SELECTION**

COLD – Move the sliding switch to “COLD”, the unit will cool and a green light will be on.

OFF – Move the sliding switch to “OFF”, the unit will be off.

## **MAINTENANCE**

- Keep cords and cigarette lighter sockets clean at all times. Small tobacco or dirt particles in the socket or the plug may affect performance.
- The motor, fan and control panel vents should be cleaned periodically. While the unit is unplugged, clean the

fan blades and motor shaft using a paint brush or other soft bristled brush. Remove all hair dirt or dust that may have accumulated.

- To clean, wipe the inside with a warm damp cloth or sponge. Do not use harsh or abrasive cleaners. A mild soap should be sufficient, but if stains or odours remain, household bleach or baking soda may be added to the washing solution. Keep the lid open for several hours after cleaning to allow the interior to thoroughly dry and to prevent odours from forming in the cooler.
- For long periods of storage, a small container of baking soda or charcoal, placed inside, will eliminate objectionable odours.

## **IMPORTANT NOTICE**

1. The power switch should be put at the "OFF" position for over 5 minutes before changing the working mode.
2. When the cooling function is on, keep in a well-ventilated area. Don't block the ventilation of the unit.
3. Do not operate under direct sunlight.
4. Do not disturb the airflow of the unit.
5. Do not pour water into the unit directly.
6. Do not use near water. Keep unit out of wet weather conditions.
7. Use damp cloth to clean the unit; do not submerge unit in water.
8. When leaving unit for a long time, put it in a well-ventilated area.
9. Avoid dropping unit.
10. Keep unit away from fire or other flammable substances.
11. Do not store meats, poultry, fish, dairy products and other items that may spoil in unit for more than one hour.
12. Use of extension cords is not recommended with this product.

Safety instruction pertaining to risk of fire, electric shock, or injury to persons

**WARNING-**When using electric products, basic precautions should always be followed, including the following:

1. Read all the instructions before using the product.
2. Do not use this product near water-for example, near a bathtub, washbowl, kitchen sink, in a wet basement, or near a swimming pool, or the like.
3. This product should be used only with a cart or stand that is recommended by the manufacturer.
4. This product, either alone or in combination with an amplifier and headphones or speakers, may be capable of producing sound levels that could cause permanent hearing loss. Do not operate for a long period of time at a high volume level or at a level that is uncomfortable. If you experience any hearing loss or ringing in the ears, you should consult an audiologist.
5. The product should be located so that its location or position does not interfere with its proper ventilation.
6. The product should be located away from heat sources such as radiators, heat registers, or other products that produce heat.
7. The product should be connected to a power supply only of the type described in the operating instructions or as marked on the product.
8. The power-supply cord of the product should be unplugged from the outlet when left unused for a long period of time.
9. Care should be taken so that objects do not fall and liquids are not spilled into the enclosure through openings.
10. The product should be serviced by qualified service personnel when:

- a) The power-supply cord or the plug has been damaged or
  - b) Objects have fallen or liquid has been spilled onto the product or
  - c) The product has been exposed to rain or
  - d) The product does not appear to operate normally or exhibits a marked change in performance or
  - e) The product has been dropped or the enclosure damaged
11. Do not attempt to service the product beyond that described in the user-maintenance instructions. All other servicing should be referred to qualified service personnel

Child entrapment warning:

DANGER or WARNING: Risk of child entrapment. Before you throw away your old mini beverage refrigerator. Take off the doors.

The appliance is not intended for use by young children or infirm persons without supervision.

Young children should be supervised to ensure that they do not play with the appliance.

To make a warranty claim, do not return this product to the store. Please email [support@curtiscs.com](mailto:support@curtiscs.com) or call 1-800-968-9853

### **1 Year Warranty**

This product is warranted to be free from defects in material and workmanship for a period of one (1) year from the date of original purchase. During this period, your exclusive remedy is repair or replacement of this product or component found to be defective, at our option; however, you are responsible for all costs associated with returning the product to us. If the product or component is no longer available, we will replace with a similar one of equal or greater value. Prior to a replacement being sent, the product must be rendered inoperable or returned to us.

This warranty does **not** cover glass, filters, wear from normal use, use not in conformity with the printed directions., or damage to the product resulting from accident, alteration, abuse, or misuse. This warranty extends only to the original consumer purchaser or gift recipient. Keep the original sales receipt, as proof of purchase is required to make a warranty claim. This warranty is void if the product is used for other than single-family household use or subjected to any voltage and waveform other than as on the specified rating on the label (e.g., 120V~60Hz).

We exclude all claims for special, incidental, and consequential damages caused by breach of express or implied warranty. All liability is limited to the amount of the purchase price. **Every implied warranty, including any statutory warranty or condition of merchantability or fitness for a particular purpose, is disclaimed except to the extent prohibited by law, in which case such warranty or condition is limited to the duration of this written warranty.** This warranty gives you specific legal rights. You may have other legal rights that vary depending on where you live. Some states or provinces do not allow limitations on implied warranties or special, incidental, or consequential damages, so the foregoing limitations may not apply to you.

For faster service, locate the model, type, and serial numbers on your appliance.

ATTACH YOUR PROOF OF PURCHASE HERE. PROOF OF PURCHASE IS REQUIRED TO OBTAIN WARRANTY SERVICE.

Please have the following information available when you contact the Support Team:

- Name, address and telephone number.
- Model number and serial number.
- clear, detailed description of the problem.


- Proof of purchase including dealer or retailer name, address and date of purchase.

**For service assistance and product information, please call: 1-800-968-9853.**

**Curtis International Ltd.**

**7045 BECKETT DRIVE. UNIT 15. MISSISSAUGA, ON, L5S 2A3 [www.curtisint.com](http://www.curtisint.com)**

## Documents / Resources

	<p><b><a href="#">BUD LIGHT MIS137BULT-6COM 6 Can Mini Retro Beverage Fridge</a></b> [pdf] Owner's Manual  MIS137BULT-6COM 6 Can Mini Retro Beverage Fridge, MIS137BULT-6COM, 6 Can Mini Retro  Beverage Fridge, Retro Beverage Fridge, Beverage Fridge, Fridge</p>
---	---

## References

-  [Curtis International - Affordable TVs, electronics and appliances](#)