



BUGANI BS12304 Portable Bluetooth Speaker User Manual

[Home](#) » [Bugani](#) » BUGANI BS12304 Portable Bluetooth Speaker User Manual 



PORTABLE BLUETOOTH SPEAKER
BRIEF PLUS
Model/HVIN:BS12304




USER MANUAL
REAL JAZZ MUSIC SPEAKER

Contents

- 1 PRODUCT OVERVIEW
- 2 CHARGE THE SPEAKER
- 3 POWER ON / OFF
- 4 BLUETOOTH CONNECTION
- 5 AUX IN
- 6 USB IN (AUDIO)
- 7 BLUETOOTH BROADCAST MODE ONLY FOR THE SAME MODEL)
- 8 BUTTON CONTROLS
- 9 RESET
- 10 BUGANI LIMITED WARRANTY
- 11 FCC STATEMENT
- 12 Documents / Resources
 - 12.1 References
- 13 Related Posts


PRODUCT OVERVIEW

- Speaker — lpc
- USB-C Cable — lpc
- AUX IN Cable — lpc
- User Manual — lpc
- Quick Start Guide — lpc



1. Multi-function Button
2. Knob Actuator
3. AUX IN
4. USB IN (Audio)
5. USB-C
6. RESET


CHARGE THE SPEAKER






	Blinking red light	Charging
	Red light off	Fully charged

Don't plug the cable in when your speaker and the charging port are not completely dry. Leave your speaker in a dry area with some airflow to let the port air dry naturally.

POWER ON / OFF




Press and hold the Power button for 2 seconds to power on.
Press and hold the Power button again for 2 seconds to power off.


	Press for two seconds	Power on
	White light on	
	Press for two seconds	Power off
	White light off	




The speaker switches off when audio has stopped or buttons have not been pressed for 15 minutes.

BLUETOOTH CONNECTION

- For first time use and turning on, the speaker will automatically enter a waiting mode for connection.
- If the Bluetooth device is already connected, press "  " button to disconnect the current connection and connect with other devices.
- The speaker will automatically enter pairing mode if it is not connected to a Bluetooth device. When pairing, enable the Bluetooth function of the device and search for " BUGANI Brief Plus " to connect.


When the connection is successful, you will hear a prompt tone and the Bluetooth indicator will turn from blinking to keeping solid.



	Press and hold for two seconds	Automatically enter Bluetooth pairing mode after turning on
	Blinking White	Bluetooth pairing
	Solid White	Bluetooth connected

AUX IN


Connect a device to the AUX IN jack with an audio cable.



USB IN (AUDIO)

Plug a USB storage device that contains playable audio contents into the USB port of the speaker.

- The speaker switches to the USB source automatically.
- Audio playback will start automatically.





BLUETOOTH BROADCAST MODE ONLY FOR THE SAME MODEL)

Set one "Brief Plus" as the main speaker, and you can connect it to more than 100 auxiliary "Brief Plus" speakers to control their functions.

1. First, connect one of the "Brief Plus" speakers to your Bluetooth device (such as a mobile phone) as the main speaker.
2. Press the "🔊" button twice on the main speaker and other "Brief Plus" speakers to enter Bluetooth broadcast connection mode and connect automatically.
3. After successful connection, the "🔊" LED indicator on the main speaker will continue to flash, and the "🔊" LED indicator on the auxiliary speaker will change from flashing to long light.

After successfully entering Bluetooth broadcast mode:

- You can turn off all speakers, adjust the volume, etc. by controlling the main speaker;
- You can turn off the power of each auxiliary speaker separately;
- You cannot adjust the volume of each auxiliary speaker separately;
- To exit Bluetooth broadcast mode, press the “ ” button on any speaker twice.




	Blinking green	Bluetooth broadcast mode
	Blinking green (speaker 1)	Bluetooth broadcast connected
	Solid green (speaker 2/3...)	

BUTTON CONTROLS

	Press and hold	Turn on/off
	Short press	Bluetooth connection/disconnect
	Double click	Bluetooth broadcast connection/disconnect
	Press and hold	Play the next song
	Short press	Play/pause
	Turn clockwise	Volume up
	Turn counterclockwise	Volume down

RESET

Press the reset button once.



CAUTION

1. It is not recommended to replace the battery privately.
2. The battery (battery pack or battery pack combination) must not be exposed to sunshine, fire or similar overheated environments.

BUGANI LIMITED WARRANTY

BUGANI Corporation "BUGANi" warrants your product against defects in materials and workmanship when purchased directly from BUGANi or a BUGANi authorized reseller. This warranty is extended only to the original end-use purchaser or the person receiving the product as a gift and shall not be extended to any other person or transferee. The warranty is valid from the date of retail purchase for a period of 1 year.

BUGANI will provide the Warranty Services in accordance with the relevant laws and regulations of local government.

This warranty does not cover defects or damage arising from improper use or maintenance, normal wear and tear, commercial use, accident or external causes. Unauthorized repair, modification or customization of your product voids this warranty.

For warranty service on covered defects during the warranty period, contact BUGANli using the contact information at worldwide. Prior to providing warranty service, BUGANi may require you to provide proof of purchase details, including but not limited to a receipt or sales invoice.

FCC STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) This device must accept any interference received. Including interference that may cause undesired operation.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.
FCC ID: 2BGTK-BS12304


IC CAUTION:

Radio Standards Specification RSS-Gen, issue 5
This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada’s licence-exempt RSS(s). Operation is subject to the following two conditions:
This device may not cause interference.
This device must accept any interference, including interference that may cause undesired operation of the device.

RF exposure statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.
For more information, please visit www.bugani-global.com

Documents / Resources

	BUGANI BS12304 Portable Bluetooth Speaker [pdf] User Manual BS12304, BS12304 Portable Bluetooth Speaker, Portable Bluetooth Speaker, Bluetooth Speaker, Speaker
---	--

References

- [User Manual](#)

[Manuals+.](#) [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.