

BuzzTV E1-E2 Android Box Essentials with Remote User Manual

Home » buzztv » BuzzTV E1-E2 Android Box Essentials with Remote User Manual



Contents

- 1 BuzzTV E1-E2 Android Box Essentials with
- Remote
- 2 Connection
- 3 Troubleshooting
- 4 Remote + Button List
- **5 Learning Remote Feature**
- 6 Lights & Indicators
- **7 Warranty Information**
- 8 Documents / Resources
 - 8.1 References
- 9 Related Posts



BuzzTV E1-E2 Android Box Essentials with Remote






Connection

AV Connection

- Connect the AV cable of the 3 colors (red/white/yellow) to the STB's AV output interface, and the other end to the TV's AV input interface. The connection can be made by colour.
- Power on the STB. Set the TV video mode to AV input.

HDTV Connection

- Connect the HDMI cable to the STB output interface, and the other end to the TV's HDMI input interface.
- Power on the STB. Set the TV video mode to HDTV input.




Troubleshooting

Warning:

Under no circumstances should you try to repair the STB by yourself, as this will invalidate the warranty. Do not open it as there is a risk of electrical shock. If any fault occurs, please first check with this troubleshooting checklist. If you are unable to remedy a problem by following this guide, contact your dealer for help.

Problem	Solution
No Power	Check if the power adapter is properly connected to the power and the TV box Press the power on the remote controller to turn on the power
No Picture	Re-Connect the HDTV cable or AV cable Check if the TV is powered on
No sound or distorted s ound	Adjust the volume Check that the speakers are connected correctly
The TV box does not re spond to the remote con trol	 Aim the remote control directly at the sensor on the front of the TV box Reduce the distance to the TV box Replace batteries in the remote control Possibility of a system crash, disconnect and reconnect the power supply
No sound during playba	The audio codec may not be supported by the TV box Check the volume
The contents of the US B or flash drive cannot b e read	 The USB or flash drive format is not compatible with the box If one of the USBs can not be read, please turn o the TV box for 30 seconds and re start the TV box
Slow operation of the U SB flash drive	Large file size or high-resolution USB flash drive takes longer time to read and display on the TV screen
The TV screen is blank and the player LED is bl inking	 Turn o the TV box, wait 30 seconds, and turn it on again Check if the HDTV connection is correct or try changing the HDTV cable

Remote + Button List



Learning Remote Feature

Learning methods please see below:

- Press and hold "Power"+"OK" for more than 3 seconds, and the LED will be turned on, indicating the remote has entered learning mode.
- Align the IR tube of the remote control with the IR tube of the remote control which needs to be learned within
- Press the "TV Power" button on the remote control, the LED will change from long light to slow flashing, waiting
 to receive the learning signal. Press the button of the remote control which needs to be learned and keep it
 sending the IR code. When the remote controller receives the learning signal, the LED flashes 3 times and then
 long light, indicating that the learning signal is received.
- Repeat step c to learn the "Source" key.
- Press the "OK" key, then the LED is turned off, indicating the code has been saved, and exit the learning mode.

Lights & Indicators

Status Lighting on the Front of STB indicates the following:

• Red - OFF

Warranty Information

For warranty information and registration, please visit www.buzztv.com/register.

support

www.buzztv.com/support. cs@buzztv.com.

Documents / Resources



BuzzTV E1-E2 Android Box Essentials with Remote [pdf] User Manual

E1-E2 Android Box Essentials with Remote, E1-E2, Android Box Essentials with Remote, Essentials with Remote

References

- <a>buzztv.com/register
- <a>buzztv.com/support

Manuals+,