CaddyTalk minion Smallest Golf Rangefinder





# CaddyTalk minion Smallest Golf Rangefinder User Manual

Home » CaddyTalk » CaddyTalk minion Smallest Golf Rangefinder User Manual



#### **Contents**

- 1 CaddyTalk minion Smallest Golf Rangefinder
- **2 Product Information**
- **3 Product Usage Instructions**
- 4 FAQs
- **5 INTRODUCTION**
- **6 PACKAGE INCLUDES**
- **7 DESCRIPTIONS**
- **8 LCD DESCRIPTION**
- 9 POWER & MEASUREMENT
- 10 MODE BUTTON OPERATION
- 11 HARD CASE
- 12 BATTERY LEVEL / CHARGING
- 13 SPECIFICATION
- 14 SAFETY WARNING CARE AND

**MAINTENANCE** 

- 15 Documents / Resources
  - 15.1 References

CaddyTalk

CaddyTalk minion Smallest Golf Rangefinder



#### **Product Information**

### Specifications:

• Charger Type: C-type cable included

• Recommended Charger: V, A charger

• Charging Method: Plug in the charging cable

• Caution: Avoid high-speed chargers to prevent overvoltage and overheating

## **Product Usage Instructions**

### • Battery Cover Removal:

- Hold both sides of the battery cover's protrusions firmly.
- Gently pull downward to remove the battery cover.

# Charging the Product:

- Ensure the battery cover is removed.
- Plug in the provided C-type charging cable into the charging port of the product.
- Connect the other end of the cable to a V, A charger.
- Avoid using high-speed chargers to prevent overvoltage and overheating.
- Once connected, charging will start automatically.

### **FAQs**

### • Q: Can I use any charger to charge the product?

• **A:** It is recommended to use a V, and A charger to prevent damage to the product.

# · Q: What should I do if I encounter overheating during charging?

• **A:** Disconnect the charger immediately and allow the product to cool down before attempting to charge again.


### • Q: Can I charge the product with the battery cover on?

• **A:** No, it is necessary to remove the battery cover before charging the product.

### INTRODUCTION

- Thank you for purchasing the CaddyTalk Minion Golf Laser Rangefinder.
- · As a manufacturing brand specializing in IT golf products,
- CaddyTalk aims to make new and improved golf products for everyone to enjoy the sport of golf.
- We hope you enjoy our smallest, feature-packed laser rangefinder designed to give you accurate distance measurements while seamlessly fitting into your pocket.
  - Please read this manual carefully before using the product.
  - Please keep the product instructions well for future reference.
  - The entire contents of this User's Guide are written by CaddyTalk and cannot be reproduced, transmitted, recorded, or stored in a search system in any form or by any means without prior permission, and cannot be translated into any other language.
  - The picture and display shown in the product manual may differ from the actual product.
  - We are not responsible for any errors that are not included in the product's user manual.
  - Appearance, specification and functionality of this product are subject to change without notice.

# **PACKAGE INCLUDES**




## **DESCRIPTIONS**

- 1. Power and Measurement Button
- 2. Mode Button(Slope On/Off, M or Yd shift)

- 3. Objective Lens (6x lens)
- 4. Laser Aperture
- 5. Focus Ring (Focus control application)
- 6. View Finder
- 7. Battery Component
- 8. Locking Lever
- 9. Belt Clip




# **LCD DESCRIPTION**




- 1. Targeting Crosshair
- 2. Active Laser
- 3. Magic Slope sign
- 4. Slope-adjusted distance
- 5. Straight Line Distance / Slope Angle
- 6. Distance Unit (Meter / Yard)
- 7. Low Battery Mark


# **POWER & MEASUREMENT**


- Press the power button to turn the device on.
- Aim the reticle at the target and press the power button again to measure the distance.
- 1. Press the power button and enable display.
- 2. Align the crosshair with the target, and press the power button.





- 3. Slope-adjusted distance is displayed.
- 4. Straight line distance is displayed.






Automatic power off when the button is not pressed for 10 seconds

# **MODE BUTTON OPERATION**


Set unit of measurement (Default: Meter)

• Each time the M button is pressed, the distance display unit changes to meter (M) – yard (Yd).




# Magic Slope ON/OFF Settings (Default: ON)

• Pressing the M button for about 2 seconds changes the slope function to ON/OFF order.




# **MAGIC SLOPE**

• Considering the altitude (high & low) of the target point, This function shows the best recommendation.




- The M-Slope is developed directly in the golf zone by applying the concept of ballistics.
- CaddyTalk's Magic Slope provides higher accuracy of recommended distances compared to existing rangefinders.
- See the differences in ballistics between CaddyTalk and other generic products.




### **HD LASER SYSTEM**

- Applying the transverse laser system, CaddyTalk's Minion fires-horizontal lasers to quickly detect pins.
- This allows for quick and accurate target detection even with shaking hands.



# **PIN FINDER**

- Hold the measurement button while you scan the viewfinder left and right.
- Only the distance to the nearest target of the scanned target is displayed.



# **JOLT**

• When the correct distance is displayed after pressing the measurement button, the completion of the measurement will be notified through a vibration alert.



# **HARD CASE**

• The belt clip allows you to attach and detach the product quickly.



# **BATTERY LEVEL / CHARGING**

- The remaining battery level, displayed in the upper right corner of the viewfinder, indicates the device's power status.
- Note that if the battery level drops below 20%, the JOLT function will not be activated.



- Hold both sides of the battery cover's protrusions and gently pull downward.
- Plug in the charging cable to start charging (5V, 2A charger recommended, C-type cable included)
- Overvoltage and overheating can cause damage to the product when using high-speed chargers (over 5V, 2A).

### **SPECIFICATION**

Product	CAODYTALKMINION
Dimensions/Size	99g/L92xH45x W29mm
Туре	Formeasuringgolfdistance
Range	3-700m/3.2~765yd
Distance Unit	M(Meter)/Yd(Yard)
Magnification	6X
Battery Type	S00mAh rechargeable internal battery
	Approx. 8,000 times actuations{FullCharge)
LaserClas6ify	CLASS!
Colour	Please see the colour name of the package
Water Resistance	IP54
Package Includes	CaddyTalk MINION, Hard Case, USB cable, User Guide, Microfiber Cloth
Manufacturer	RNDUS CO., LTD./ Designed and Patented by Korea, Made in China
Support	info@caddytalkusa.com
Website	www.caddytalkusa.com


### SAFETY WARNING CARE AND MAINTENANCE

Please read the manual carefully before using the device.

- 1. Avoid touching the lens with your hands to protect it from foreign substances.
- 2. Do not disassemble or attempt to repair the product on your own.
- 3. Wipe the lens and viewfinder with a soft, clean cloth to remove foreign substances.
- 4. Store the product in a well-ventilated space at room temperature.
- 5. Keep the device away from heavy rain or water, as it features only basic water resistance.
- 6. Avoid exposing the lens and viewfinder to direct sunlight to prevent equipment failure.
- 7. Do not stare directly at the laser beam.
- 8. Use with care according to your purpose.

- 9. Objects in front of the laser (e.g. glass, insects, screens, etc.) may affect the accuracy of distance measurement.
- 10. Keep away from children.
- 11. Depending on the environment, a 'beep' sound may occur when the device is in operation.
- 12. Environmental factors (e.g. snow, rain, fog, etc.) may affect the device.
- 13. Charge the battery regularly to prevent it from completely draining. Note that frequent full charges may reduce battery life.
- 14. Due to the device's design, part replacements are not possible.
- 15. Stains or scratches on clothes and belts may occur in some cases when using the hard case.

### **Documents / Resources**



#### References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.