



CAL-ROYAL 5000E0 Rim Panic Exit Device Instruction Manual

[Home](#) » [CAL-ROYAL](#) » CAL-ROYAL 5000E0 Rim Panic Exit Device Instruction Manual 



5000E0 RIM PANIC EXIT DEVICE INSTALLATION INSTRUCTIONS

Contents

- [1 5000E0 Rim Panic Exit Device](#)
- [2 TYPE OF INSTALLATION](#)
- [3 APPLY HARDWARE](#)
- [4 APPLY RAIL ASSEMBLY](#)
- [5 APPLY COVER AND STRIKES](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)

5000E0 Rim Panic Exit Device


BEFORE INSTALLING DEVICE, PLEASE CHECK:

1. IF DOOR FITTED AND HUNG.
2. SIZE OF EXIT DEVICE FUNCTION AND DESIGN...


2.1.36"DOORS,CAN BE CUT TO FIT DOORS DOWN TO 30" WIDE.

2.2.48"DOORS,CAN BE CUT TO FIT DOORS DOWN TO 36" WIDE.

2.3.HAND OF DEVICE AGAINST APPLICATION.





TYPE OF INSTALLATION



APPLY HARDWARE


2.1. DRILL HOLES

MARK DOOR FACE AND DRILL HOLES IN ACCORDANCE WITH THE DIAMETERS SUGGESTED . SEE ATTACHED TEMPLATE.




CENTER OF CYLINDER END OF BODY INSIDE FACE OF THE DOOR


2.2. INSTALL CYLINDER



1. INSERT THE CYLINDER THROUGH CYL RING THE HOLE ON THE DOOR
2. KEEP THE TAILPIECE HORIZONTAL.
3. MOUNT LINER ON INSIDE OF DOOR A4. TAILPIECE PROJECTION OVER INSIDE OF DOOR IS SUGGESTED IN THE RANGE 9/32"~15/32". IF NECESSARY, USE A PLIER TO BEND AND CUT TO DESIRED LENGTH.




2.3. INSTALL LEVER,OR KNOB,OR PULL TRIM





APPLY RAIL ASSEMBLY

1. CHECK THE SIZE OF DEVICE ,IF CUTTING LENGTH IS REQUIRED.
2. DETERMINE CUT OFF LENGTH "X"BY SUBTRACTING 1 3/4" FROM "Y".MARK CUT OFF POINT ON MOUNTING RAIL.
3. DEPRESS ARM INTO RAIL OPENING AND SLIDE RAIL ONTO CHASSIS .LEVER RAIL AND FASTEN CHASSIS AND MOUNTING PLATE.



APPLY COVER AND STRIKES



ATTACH COVER TO CHASSIS WITH (4)#8TRUSS HEAD MACHINE SCREWS


ATTACH END CAP TO MOUNTING PLATE WITH (2)COVER SCREWS

ATTACH STRIKE TO DOOR STOP WITH (2)STRIKE SCREW AND LOCK WASHER



EDG-4106-10/23

Documents / Resources



[CAL-ROYAL 5000E0 Rim Panic Exit Device](#) [pdf] Instruction Manual
5000E0 Rim Panic Exit Device, 5000E0, Rim Panic Exit Device, Panic Exit Device, Exit Device

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.