


CALIMET
CM9-976 Digital Timer Switch



CALIMET CM9-976 Digital Timer Switch Instructions

[Home](#) » [CALIMET](#) » CALIMET CM9-976 Digital Timer Switch Instructions 

Contents

- [1 CALIMET CM9-976 Digital Timer Switch](#)
- [2 Specifications](#)
- [3 Digital Timer Wire Connection](#)
- [4 Setting Weekly Schedule](#)
- [5 Program Digital Timer](#)
- [6 FAQs](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)

CALIMET

CALIMET CM9-976 Digital Timer Switch




Specifications

- **Model:** CM9-976 Digital Timer Switch
- **Power Supply:** 24V DC
- **Operating Mode:** Auto/Manual
- **Programming:** Weekly schedule

Digital Timer Wire Connection

Refer to the following diagram for the wire connection:



Setting Weekly Schedule

1. Press the WEEK button to select the desired day(s) of the week.
2. Use the HR (hour) and MM (minute) buttons to set the desired time.
3. Select ON or OFF for the scheduled event.

Switching between Auto and Manual Mode

To switch between Auto and Manual modes, press the AUTO/MANUAL button on the device.

Safety Features

The device is equipped with safety features such as phantom open/loop detection for added security.

Program Digital Timer

1. Use a pin and press “C”, once the digital screen is reset.
2. Press “D+” to set the current day, “H+” hour, and “M+” minute.
3. Press “⌚” after finishing setting the date and time.
4. Press “P” to select program setting 1 (total of 28 program settings). The user should see “1 ON” (opening time). Press “D+” to set the days that are needed, “H+” for the hour, and “M+” for the minute.
5. Press “P” again to select the program setting “1 OFF” (closing time). Press “D+” to set the days that are needed, “H+” for the hour, and “M+” for the minute.
6. Follow Setp 4 and 5 until finish programmed the timer.
7. Press “⌚” aftthe er finish.

NOTE: To disable the digital timer, click on “Manual”.

FAQS


Q: How do I reset the timer to factory settings?

A: To reset the timer to factory settings, press and hold the RESET button for 10 seconds.

Q: Can I program multiple schedules for the same day?

A: Yes, you can program multiple schedules for the same day by following the steps for setting a weekly schedule repeatedly.

Documents / Resources

	<p>CALIMET CM9-976 Digital Timer Switch [pdf] Instructions</p> <p>CM9-976 Digital Timer Switch, CM9-976, Digital Timer Switch, Timer Switch, Switch</p>
---	---

References

- [User Manual](#)

[Manuals+.](#) [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.