



canvas Rehearsal Box User Guide

[Home](#) » [Canvas](#) » canvas Rehearsal Box User Guide 

Contents

- 1 [canvas Rehearsal Box](#)
- 2 [Specifications:](#)
- 3 [QUICK Usage Instructions:](#)
 - 3.1 [Setting Up:](#)
 - 3.2 [Setting Tempo and Metronome:](#)
 - 3.3 [Playing Along with Songs:](#)
 - 3.4 [Adjusting Levels:](#)
 - 3.5 [Additional Resources:](#)
- 4 [FAQ:](#)
 - 4.1 [Q: What type of power supply is recommended for the Canvas Rehearsal?](#)
 - 4.2 [Q: How can I get support or assistance with the product?](#)
- 5 [Documents / Resources](#)
 - 5.1 [References](#)
- 6 [Related Posts](#)

canvas Rehearsal Box



USER GUIDE

Thanks for choosing the Canvas Rehearsal as your all-in-one rehearsal utility. Simply connect it to the end of your pedal chain, plug in some headphones, and you're ready to rehearse!

To get started, simply set your tempo by tapping it in or use the encoder to dial in a specific BPM. Press the Start/Stop switch to turn the metronome on and off.

Want to practice along with a song? Use the 1/8" Auxiliary input or pair the Rehearsal with a Bluetooth enabled device to play along with a track.

Use the Guitar, Click, and AUX knobs to mix levels to taste. The Headphone volume knob will then adjust the overall mix.



The use of an isolated power supply is recommended for powering all Walrus Audio Pedals. Daisy chain power supplies are not recommended.



View the full manual, register your pedal, watch videos, and more by scanning the QR code on the reverse side.

9 volt DC, Center Neg. 300mA min*



This product comes with a limited lifetime warranty. Scan the code above to register your pedal, view the full manual, leave a review and more.



Specifications:

- Power Supply: 9 volt DC, Center Negative, 300mA min*
- Recommended Power Supply: Isolated power supply
- Warranty: Limited lifetime warranty

QUICK Usage Instructions:

Setting Up:

1. Connect the Canvas Rehearsal to the end of your pedal chain.
2. Plug in headphones to the headphone output.
3. Power the unit using a 9V DC power supply with center negative polarity.

Setting Tempo and Metronome:

1. Set the tempo by tapping it in or use the encoder to dial in a specific BPM.
2. Press the Start/Stop switch to turn the metronome on and off.

Playing Along with Songs:

1. Use the 1/8 Auxiliary input to connect an external audio source.
2. Pair the Rehearsal with a Bluetooth enabled device to play along with a track.

Adjusting Levels:

1. Use the Guitar, Click, and AUX knobs to mix levels according to your preference.
2. Adjust the overall mix using the Headphone volume knob.

Additional Resources:

Scan the QR code on the reverse side for access to the full manual, registration, instructional videos, and more.



We also staff a real live human to answer emails for repairs, questions, and general life advice.

help@walrusaudio.com

- [INSTAGRAM/WALRUSAUDIOEFFECTS](#)
- [FACEBOOK /WALRUSAUDIO](#)
- [X/ WALRUSAUDIO](#)
- [YOUTUBE/WALRUSAUDIOEFFECTS](#)

FAQ:


Q: What type of power supply is recommended for the Canvas Rehearsal?

A: An isolated power supply is recommended for powering all Walrus Audio Pedals. Do not use daisy chain power supplies.

Q: How can I get support or assistance with the product?

A: You can contact help@walrusaudio.com for repairs, questions, or general advice. You can also register your pedal and access resources by scanning the provided QR code.

Documents / Resources

	canvas Rehearsal Box [pdf] User Guide Rehearsal Box, Rehearsal Box, Box
---	--

References

- [User Manual](#)

Manuals+. Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.