

Contents [[hide](#)]

- [1 CASIO 3294 DST Setting Module](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 Adjusting Time](#)
- [5 FAQs](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)

CASIO

CASIO 3294 DST Setting Module



Specifications

- Model: 3294

- Mode: Timekeeping
- Functionality: DST Setting

Product Usage Instructions

1. In the Timekeeping mode, press .



2. The seconds start to flash.
3. Press once. "Hours" will flash.



4. Press to change the hour.



5. Press to return to the Timekeeping Mode.

<Timekeeping Mode Screen>



Setting DST

Ensure the watch is in Timekeeping Mode.

Firstly, make sure it is in the Timekeeping Mode.

<Timekeeping Mode Screen>



- To return to the Timekeeping Mode, Press  several times.

Adjusting Time

- Press the button to make the seconds flash.
- Press the button once to make the hours flash.
- Use the button to adjust the hour.
- Press the button to return to Timekeeping Mode.

FAQs


Q: How do I switch between DST settings?

A: To switch between DST settings, follow the steps provided in the user manual while ensuring you are in the Timekeeping Mode.

Q: What should I do if the time does not adjust correctly?

A: If the time does not adjust correctly, double-check that you are following the steps accurately. If issues persist, refer to the troubleshooting section in the user manual or contact customer support.

Documents / Resources

	CASIO 3294 DST Setting Module [pdf] Instructions 3294, 3294 DST Setting Module, DST Setting Module, Setting Module, Module
---	---

References

- [User Manual](#)

3294, 3294 DST Setting Module, Casio, DST Setting-Module, Module, Setting-Module

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.