



CASIO 3416 DST Setting-Module Instructions

[Home](#) » [Casio](#) » CASIO 3416 DST Setting-Module Instructions 

CASIO

3416 DST Setting-Module
Instructions



Contents

[1 3416 DST Setting-Module](#)

[2 Documents / Resources](#)

[3 Related Posts](#)

3416 DST Setting-Module

DST Setting / Module : 3416


Firstly, make sure it is in the Timekeeping Mode.

<Timekeeping Mode Screen>



To return to the Timekeeping Mode, hold down  for two seconds



In the Timekeeping Mode, hold down  until the seconds start to flash.



Press **C** once. “Hours” will flash.



Press **B** or **D** to change the hour.



Press **A** to return to the Timekeeping Mode.



CASIO

Documents / Resources

	CASIO 3416 DST Setting-Module [pdf] Instructions 3416 DST Setting-Module, 3416, DST Setting-Module, Setting-Module, Module
---	--