



CASIO 3461 DST Setting Watch Instructions

[Home](#) » [Casio](#) » CASIO 3461 DST Setting Watch Instructions 

Contents

- [1 CASIO 3461 DST Setting Watch](#)
- [2 Product Information](#)
- [3 Product Usage Instructions:](#)
- [4 DST Setting / Module](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)

CASIO®

CASIO 3461 DST Setting Watch



Product Information

The product is a watch with a DST (Daylight Saving Time) setting module numbered 3461. It can be connected to a mobile phone via an app. The watch has a Timekeeping Mode and a DST setting mode. The DST setting can be changed to AUTO/OFF/ON. The watch also has a City Code feature.

Product Usage Instructions:

1. Ensure that you are not connected to the mobile phone app before proceeding with the DST setting.
2. Make sure that the watch is in the Timekeeping Mode. To return to the Timekeeping Mode, hold down the button labeled HT for two seconds.
3. In the Timekeeping Mode, hold down the button labeled HT until HT flashes.
4. Press the button labeled DST Setting once to display the DST setting mode.
5. Press the button labeled HT to change the DST setting. The options are AUTO/OFF/ON.
6. Press the button labeled DST Setting again to return to the Timekeeping Mode.

DST Setting / Module

- If you are connected to a mobile phone, please switch from the app.

Firstly, make sure it is in the Timekeeping Mode. <Timekeeping Mode Screen>



1. To return to the Timekeeping Mode, hold down **C** for two seconds.




2. In the Timekeeping Mode, hold down **A** until "HT" flashes.



3. Press **C** once to display the DST setting mode.




4. Press **A** to change the DST Settings. AUTO/OFF/ON




5. Press **C** to return to the Timekeeping Mode.

<Timekeeping Mode Screen>



Documents / Resources

	<p>CASIO 3461 DST Setting Watch [pdf] Instructions 3461, 3461 DST Setting Watch, DST Setting Watch, Watch</p>
---	---