



CASIO 5398 DST Setting and Module Instructions

[Home](#) » [Casio](#) » CASIO 5398 DST Setting and Module Instructions 

CASIO®

5398 DST Setting and Module
Instructions

Contents

- [1 5398 DST Setting and Module](#)
- [2 Documents / Resources](#)
- [3 Related Posts](#)

5398 DST Setting and Module

Firstly, make sure it is in the Timekeeping Mode.

<Timekeeping Mode Screen>



To return to the Timekeeping Mode, hold down **C** for two seconds.

1. In the Timekeeping Mode, hold down **C** until the city code appears on the upper display.



2. Press **A** once to display the DST Setting Mode.



3. Rotate the rotary switch to toggle between "ON" and "OFF".



4. Press to return to the Timekeeping Mode.



<Timekeeping Mode Screen>



CASIO®

	CASIO 5398 DST Setting and Module [pdf] Instructions 5398, DST Setting and Module, 5398 DST Setting and Module, Module
---	--