



CASIO HK-W Smart Watch User Guide

[Home](#) » [Casio](#) » CASIO HK-W Smart Watch User Guide 

Contents

- [1 CASIO HK-W Smart Watch](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 INSTALLATION INSTRUCTION](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)

CASIO

CASIO HK-W Smart Watch



Product Information

This product is an analog watch with various modules (1362, 1398, 1770, 2799, 3378, 4370, 705, 706, 1300, 1311, 1330, 1344, 1360, 1399, 1747, 1771, 4394, 5049, 1782, 4328, 4747, 707, 708, 1331, 1332, 1342, 1345, 1346, 1787, 2717, 2718, 2719, 2725, 2731, 2748, 2749, 2783, 2784, 3363, 3711, 3712, 4393, 5025, 5044, and 4746). It has a crown that is used to set the time and other functions depending on the module. It also features an elapsed time bezel for certain models.

Specifications

- **Module:** Various
- **Watch Type:** Analog
- **Language Options:** English and Spanish

Product Usage Instructions

Crown (Modules: 1362, 1398, 1770, 2799, 3378, 4370)

1. Pull out the crown.
2. Set the hands by rotating the crown.
3. Push the crown back in on a time signal to resume timekeeping.

Crown (Modules: 705, 706, 1300, 1311, 1330, 1344, 1360, 1399, 1747, 1771, 4394, 5049)

1. When the second hand is at 12 o'clock, pull out the crown to stop it.
2. Set the hands by rotating the crown. Move the minute hand four or five minutes past the setting you want, and then back them up to the setting.
3. Push the crown back in on a time signal to resume timekeeping.

Crown (Modules: 1782, 4328, 4747)

1. When the second hand is at 12 o'clock, pull out the crown to the second click to stop it.
2. Set the hands by rotating the crown. Move the minute hand four or five minutes past the setting you want, and then back them up to the setting.
3. Push the crown back in on a time signal to resume timekeeping.
4. The second click is for the time setting.

Crown (Modules: 707, 708, 1331, 1332, 1342, 1345, 1346, 1787, 2717, 2718, 2719, 2725, 2731, 2748, 2749, 2783, 2784, 3363, 3711, 3712, 4393, 5025, 5044)

1. When the second hand is at 12 o'clock, pull out the crown to the second click to stop it.
2. Set the hands by rotating the crown. Move the minute hand four or five minutes past the setting you want, and then back them up to the setting.
3. Push the crown back in on a time signal to resume timekeeping.
4. The first click is for the day setting.

Crown (Module: 4746)

1. When the second hand is at 12 o'clock, pull out the crown to the second click to stop it.
2. Set the hands by rotating the crown. Move the minute hand four or five minutes past the setting you want, and then back them up to the setting.
3. Push the crown back in on a time signal to resume timekeeping.
4. The first click is for the day and day of the week setting.

FAQ

How do I set the time on my watch?

- The time can be set by pulling out the crown, rotating it to set the hands, and pushing it back in on a time signal to resume timekeeping. Please refer to the specific instructions for your watch module.

How do I set the day and day of the week on my watch?

- To set the day and day of the week, pull out the crown to the first click, rotate it to set the desired day and day of the week, and push it back into its normal position.
- Please refer to the specific instructions for your watch module.

How do I use the elapsed time bezel?

- For watches with an elapsed time bezel, rotate it to align the mark with the minute hand. After a certain amount of time has elapsed, read the graduation on the bezel indicated by the minute hand.
- This will display the elapsed time. Please note that not all watch modules have an elapsed time bezel.
- Your watch may differ somewhat from the one shown in the illustration.

INSTALLATION INSTRUCTION

- **[Modules 1362, 1398, 1770, 2799, 3378, 4370]**

To set the time


- Pull out the crown. Set the hands by rotating the crown. Push the crown back in on a time signal to resume timekeeping.



- **[Modules 705, 706, 1300, 1311, 1330, 1344, 1360, 1399, 1747, 1771, 4394, 5049]**

To set the time



1. When the second hand is at 12 o'clock, pull out the crown to stop it.
2. Set the hands by rotating the crown. Move the minute hand four or five minutes past the setting you want, and then back them up to the setting.
3. Push the crown back in on a time signal to resume timekeeping.



[Modules 707, 708, 1331, 1332, 1342, 1345, 1346, 1787, 2717, 2718, 2719, 2725, 2731, 2748, 2749, 2783, 2784, 3363, 3711, 3712, 4393, 5025, 5044]

To set the time

1. When the second hand is at 12 o'clock, pull out the crown to the second click to stop it.
2. Set the hands by rotating the crown. Move the minute hand four or five minutes past the setting you want, and then back them up to the setting.
3. Push the crown back in on a time signal to resume timekeeping.



To set the day


Avoid setting the day between 8:00 p.m. and 2:00 a.m. The day may not change in the following day if you do.

1. Pull out the crown with the first click.
2. Set the day by rotating the crown.
3. Push the crown back into its normal position.

[Modules 709, 1333, 1347, 3716]

To set the time

1. When the second hand is at 12 o'clock, pull out the crown to the second click to stop it.
2. Set the hands by rotating the crown. Move the minute hand four or five minutes past the setting you want, and then back them up to the setting.
3. Push the crown back in on a time signal to resume timekeeping.




[Days of the Week]

English	Spanish
SUN	DOM
MON	LUN
TUE	MAR
WED	MIER
THU	JUEV
FRI	VIER
SAT	SAB

To set the day and day of the week


- Avoid setting the day and day of the week between 8:00 p.m. and 4:00 a.m.
 - The day and day of the week may not change on the following day if you do.
1. Pull out the crown with the first click.
 2. Set the day by rotating the crown counterclockwise.
 3. Set the day of the week by rotating the crown clockwise. Confirm that the correct language (English or Spanish) is selected.
 4. Push the crown back into its normal position.

- For the watch with the elapsed time bezel Rotate the elapsed time bezel to align the mark with the minute hand.
- After a certain amount of time elapsed, read the graduation on the elapsed time bezel which the minute hand points to.
- The elapsed time is indicated.




Elapsed time bezel

- Some water-resistant models are equipped with a screw lock crown.
- With such models, you must unscrew the crown in the direction noted in the illustration to loosen it before you can pull it out. Do not pull too forcibly on such crowns.
- Also, note that such watches are not water resistant while their crowns are loosened. Be sure to screw the crowns back in as far as they will go after making any setting.



Documents / Resources



[CASIO HK-W Smart Watch](#) [pdf] User Guide
HK-W Smart Watch, HK-W, Smart Watch, Watch

References

- [User Manual](#)