

CASIO MS-20NC Color Selection Calculator User Guide

Home » Casio » CASIO MS-20NC Color Selection Calculator User Guide

Contents [hide

- 1 CASIO MS-20NC Color Selection
- Calculator
- **2 Important Precautions**
 - 2.1 Auto Power Off Function
- **3 Tax Calculations**
 - 3.1 To set a tax rate
 - **3.2 Currency Conversion**
- **4 Specifications**
- 5 Manufacturer
- 6 Documents / Resources
- 7 Related Posts



CASIO MS-20NC Color Selection Calculator



Be sure to keep all user documentation handy for future reference.

Important Precautions

- Avoid dropping the calculator and otherwise subjecting it to severe impact.
- · Never try to take the calculator apart.
- Wipe the unit with a soft, dry cloth to clean it.
- The contents of these instructions are subject to change without notice.
- CASIO COMPUTER CO., LTD. assumes no responsibility for any loss or claims by third parties which may arise from the use of this product.

Power Supply


- Two-Way Power System provides power even in complete darkness.
- Always leave battery replacement up to an authorized dealer.
- The battery that comes with this unit discharges slightly during shipment and storage. Because of this, it may require replacement sooner than the normal expected battery life.

• Auto power off: Approximately 6 minutes after last key operation

Tax Calculations

To set a tax rate

• Example: Tax rate = 5%



- . AC (SET) (Until SET appears.)
- TAX+ (TAX RATE) 5* &(SET)

You can check the currently set rate by pressing A and then S(TAX RATE).

Currency Conversion

To enter the Currency Conversion Mode

- Press m to toggle between the Conversion Mode and the Memory Mode.
- The "EXCH" indicator on the display indicates the Conversion Mode.

To set conversion rates

- Currency 1 (C1) is your home country currency, and so it is always set to 1. Currency 2 (C2) and
- Currency 3 (C3) are for the currencies of two other countries, and you can change these rates as required.

Example: Conversion rate \$1 (C1 home currency) = 0.95 euro for Currency 2 (C2)



- You can check the currently set rate by pressing A and then C.
- For rates of 1 or greater, you can input up to six digits. For rates less than 1 you can input up to 12 digits, including 0 for the integer digit and leading zeros (though only six significant digits, counted from the left and starting with the first non-zero digit, can be specified).

Examples: 0.123456, 0.0123456, 0.00000012345

Specifications


• Power Supply: Two-Way Power System, with solar cell and one button-type battery (LR44)

- Battery Life: Approximately 3 years (1-hour operation per day)
- Operating Temperature: 0°C to 40°C (32°F to 104°F)
- **Dimensions:** 22.1 (H) \times 104.5 (W) \times 149.5 (D) mm (7/8"H \times 41/8"W \times 57/8"D)
- Weight: Approximately 125 g (4.4 oz), including battery

Temperatura pracy: 0°C do 40°C

		100.
	AC	0.
$6 \div 3 \times 5 + 2.4 - 1 = 11.4$	6⊕3⋉5⊕2.4−1≡	11.4
$2 \times (-3) = -6$	2※35 ≡	-6.
1 + 5 = 6	5⊕ ⊕1 ≡	к 6.
3 <u>+ 5</u> = 8	3 ≡	к 8.
7 <u>- 6</u> = 1	6	к 1.
2-6=-4	2 🖃	к – 4.
$2 \times 3 = 6$	2※※3≡	к 6.
$2 \times 4 = 8$	4≡	к 8.
$15 \div 3 = 5$	3 🔁 🛨 15 🖃	к 5.
21 <u>÷ 3</u> = 7	21 🖃	к 7.
$\sqrt{4} \times 5 = 10$	4√ 🕱 5 🖃	10.

Conversion rate



- C1 (\$) = 1, C2 (EUR) = 0.95, C3 (FRF) = 6.1715
- 100 EUR → \$? (105.263157894)
- \$110 → FRF? (678.865)
- 100 EUR → FRF? (649.631578942)

Conversion calculation formulas

• A = Input or displayed value, B = Rate, X = C2 or C3 rate, Y = C2 or C3 rate.

Manufacturer

• CASIO COMPUTER CO., LTD.

- 6-2, Hon-machi 1-chome
- Shibuya-ku, Tokyo 151-8543, Japan

Responsible within the European Union

- CASIO EUROPE GmbH
- Casio-Platz 1, 22848 Norderstedt, Germany

Documents / Resources



<u>CASIO MS-20NC Color Selection Calculator</u> [pdf] User Guide MS-20NC, Color Selection Calculator, Selection Calculator, MS-20NC, Calculator

Manuals+, home privacy