



# CASIO WU-BT10 Wireless MIDI and Audio Adaptor User Guide

[Home](#) » [Casio](#) » CASIO WU-BT10 Wireless MIDI and Audio Adaptor User Guide

## Contents [ [hide](#) ]

- [1 CASIO WU-BT10 Wireless MIDI and Audio Adaptor](#)
- [2 WU-BT10 Wireless MIDI & audio adaptor Connection Guide](#)
- [3 Connecting the Adaptor](#)
- [4 Troubleshooting](#)
- [5 Product Specifications](#)
- [6 Documents / Resources](#)
  - [6.1 References](#)
- [7 Related Posts](#)

# CASIO

## CASIO WU-BT10 Wireless MIDI and Audio Adaptor



## WU-BT10 Wireless MIDI & audio adaptor Connection Guide



Plugging this Wireless MIDI & audio adaptor into a supported CASIO instrument provides Bluetooth connectability for Audio and MIDI data. For information on supported instruments, smart devices and apps, visit the CASIO website below. <https://web.casio.com/emi/wireless/>

### Connecting the Adaptor

**For operation details, refer to the user documentation for the instrument and apps you are using.**

1. Check to make sure that the instrument you are connecting to is turned off.
2. Plug the adaptor into the USB-A port of the instrument.

**IMPORTANT!** When plugging in or unplugging the adaptor, grasp it as shown in the illustration above. Failure to do so can cause damage or malfunction.

3. Turn on the instrument.
  - Depending on your instrument model, you may need to turn on its Bluetooth. For information about how to turn an instrument's Bluetooth on or off, refer to its user documentation.
4. **Pair the adaptor with your smart device.**
  - If you are using MIDI, use your app to connect with "WU-BT10 MIDI".
  - If you are using Audio, use your smart device's pairing function to connect with "WU-BT10 Audio".

### Troubleshooting

- **Problem:** The connection drops out.
- **Solution:** If there is another device with the same frequency bandwidth nearby, move it further away.
- **Problem:** I can't pair the adaptor with my smart device.
- **Solution:** Check to make sure the instrument's Bluetooth is turned on. See the website shown above for the latest support information.


### Product Specifications

- **Model:** WU-BT10
- **Dimensions:** 22.6 mm(W) × 36.6 mm(H) × 24.2 mm(D)
- **Weight:** Approximately 8.0 g
- **Connector:** USB-type A

- **Power Supply:** USB bus power
- **Power Consumption:** 0.25 W
- **Bluetooth Version:** 5.0
- **Supported Profile:** A2DP (Audio), GATT (MIDI over Bluetooth Low Energy)
- **Supported Codec:** SBC
- **Wireless Output :** Class1
- **Transmission Frequency Range:** 2402 to 2480 MHz

For the latest information about supported operating systems, visit the website at the URL at the top of these instructions.

## Documents / Resources

	<p><a href="#">CASIO WU-BT10 Wireless MIDI and Audio Adaptor</a> [pdf] User Guide WUBT10, BBQWUBT10, WU-BT10 Wireless MIDI and Audio Adaptor, WU-BT10, Wireless MI DI and Audio Adaptor</p>
---	---

## References

- [C WU-BT10 | CASIO](#)