



CASTLECREEK Log End Table Instruction Manual

[Home](#) » [CASTLECREEK](#) » CASTLECREEK Log End Table Instruction Manual 



Congratulations on your CASTLECREEK® purchase.

We're proud to help you furnish and enhance the place you call home.

Whether indoors or outside, CASTLECREEK® is the perfect choice for comfortable living at an exceptional value.

Item #675420 CASTLECREEK® Log End Table



Contents

[1 Log End TableAssembly Instructions](#)

[2 ADDITIONAL DETAILS / WARNINGS:](#)








[3 Documents / Resources](#)

[3.1 References](#)

[4 Related Posts](#)

Log End TableAssembly Instructions


PARTS LIST

<p>A.) Table Top 1pc</p> 	<p>B.) Back Leg Left & Right 2pcs</p> 
<p>C.) Front Leg Left & Right 2pcs</p> 	<p>D.) Side Panel 2pcs</p> 
	<p>E.) Long Support Bar 2pcs</p> 
<p>F.) Short Support Bar 3pcs</p> 	<p>G.) Screw 28pcs</p>  <p>3X30mm</p>

sportsmansguide.com


STEP ONE

Attach the three Short Support Bars (F) into the Long Support Bars (E) and secure both sides in place using Six Screws (G).




STEP TWO

Attach the Long Support Bars (E) to the Back Legs (B) and the Front Legs (C) and secure in place using eight Screws (G), two screws for each leg.



STEP THREE

Attach the Side Panels (D) to the Legs (B & C) using eight Screws (G), two screws for each leg.




STEP FOUR

Place the tabletop (A) on top of the Legs. Secure the tabletop (A) to the Side Panels (D) using four Screws (G), two screws for each side.




STEP FIVE

Remove Drawer from tabletop (A). When pulling out the drawer, lift the drawer up slightly in order to avoid the drawer stopper at the back.



STEP SIX

Secure the tabletop (A) to the Front Legs (C) using two Screws (G), one screw for each side. Slide the drawer back into place.



STEP SEVEN

Ensure all screws are fully tightened. Assembly complete.



ADDITIONAL DETAILS / WARNINGS:



WARNING: CHOKING HAZARD – Contains small parts- keeps parts and packaging away from children and pets.



WARNING: Do not sit or stand at a table.

- Read and understand all warnings, cautions, assembly, installation, and use instructions prior to assembling, installing, or using this product. Failure to follow all warnings cautions, and instructions may result in serious injury or damage to personal property.
- Confirm all parts are present before assembly. If any part is missing, cracked, or damaged, please contact Sportsman's Guide customer service before assembly.
- Assemble product on a soft surface (like the cardboard box) to protect from scratching or damaging the item and other surfaces
- Tools required (not included): Philips screwdriver
- At least two people are recommended for the safe assembly and installation of this product.
- Once assembled, make sure the product is placed on a firm, level surface.
- NEVER exceed the weight limit of 180 pounds (80kgs).
- To avoid injury, periodically check all screws for tightness during usage and check the hardware for signs of wear and possibly metal fatigue that may require repair or replacement.
- Solid wood such as this has knots and cracking which are normal and should be considered an enhancement to the natural beauty of this product.


For assistance with your product, please contact the Sportsman's Guide customer service at 1-800-888-3006 Mon.-Fri. 7:00 am to 9:00 pm, Sat.-Sun. 8:00am to 8:00pm CST or go to sportsmansguide.com/customerservice/contactus



sportsmansguide.com

Made in China
675420 – CC Log End Table

Documents / Resources

	<p>CASTLECREEK Log End Table [pdf] Instruction Manual Log End Table</p>
---	---

References

- [SG Customer Service | Sportsman's Guide](#)

[Manuals+](#).