

CCKHDD FT105 Mini USB Fingerprint Reader User Manual

Home » CCKHDD » CCKHDD FT105 Mini USB Fingerprint Reader User Manual





FT105 USB Fingerprint Encryption Unlock Logger User Manual

Contents

- 1 FT105 Mini USB Fingerprint Reader
- 2 Documents / Resources
 - 2.1 References

FT105 Mini USB Fingerprint Reader

Tip: This device only supports win10/win11 genuine, in principle, non-authentic does not support!If you must use non-authentic win10, win11, you need to create a new local administrator account.


1. Driver installation method: The original win10 and win11 do not need to install the driver, insert the fingerprint recognizer into the computer USB interface and enter the fingerprint input setting directly. The non-genuine version needs to install the driver and create a new local administrator account (For how to create a new administrator account, please find detailed methods on Google or YouTube).

In the event of a return or exchange, please send this instruction manual back together

1. Fingerprint entry and setting:

- ☆ Find Start on the desktop→Click Settings→Click Accounts in the Windows Settings
- →Click Sign-in options→Find Windows Hello Fingerprint, Click Set up→set your PIN password
- →Swipe your finger on the fingerprint sensor Continue swiping until Windows Hello setup is complete.
- →After the setup is complete, please restart your computer
- →Find your fingerprint in the login settings when you log in, then you can save yourself from entering a password

every time you log in to your computer.



Documents / Resources



CCKHDD FT105 Mini USB Fingerprint Reader [pdf] User Manual

FT105 Mini USB Fingerprint Reader, FT105, Mini USB Fingerprint Reader, USB Fingerprint Reader, Fingerprint Reader, Reader

References

• User Manual