


celexonTM
0767 Folding
Frame
Screen



celexon 0767 Folding Frame Screen Instructions


[Home](#) » [celexon](#) » celexon 0767 Folding Frame Screen Instructions 

Contents

- [1 celexon 0767 Folding Frame Screen](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 FAQs](#)
- [5 Safety instructions and warnings](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)

celexonTM

celexon 0767 Folding Frame Screen



Specifications

- Product Name: Folding Frame Screen
- Screen Type: Foldable Frame

Product Usage Instructions

Safety Instructions

Please read and follow all safety instructions before installing the Folding Frame Screen. Failure to comply may result in property damage or personal injury.

Installation

1. Ensure the area where the screen will be installed is clear and suitable for mounting.
2. Follow the provided instructions to assemble the frame securely.
3. Gently attach the screen to the frame, making sure it is evenly stretched.

Usage

When using the Folding Frame Screen:

- Avoid touching the screen surface with your hands to prevent damage.
- Do not fold the screen in low temperatures to avoid potential damage.

Maintenance

To maintain the screen's quality:

- Clean the screen gently with a soft cloth to remove dust or dirt.
- Store the screen in a dry and safe place when not in use to prevent damage.

FAQs

- **Q: Can I use the Folding Frame Screen outdoors?**
 - A: It is recommended to use the screen indoors to ensure its longevity and performance.
- **Q: How do I adjust the tension of the screen on the frame?**
 - A: Follow the provided instructions to adjust the tension evenly across all sides of the screen for optimal display.

Safety instructions and warnings

Folding Frame Screen


Please read and follow all the safety instructions below and on the product before installing the folding frame screen. Failure to comply with the safety instructions may result in property damage or personal injury and could

affect the safety features contained in the unit. Please retain all safety instructions.





- Before installation, please refer to the datasheet for further safety and use instructions.
- Do not begin installation until you have read and understood the complete operating instructions.
- Carry out the installation with another person to ensure safe installation.
- Remove the product from its packaging and remove all packaging materials.
- Make sure that there is no packaging material on or in the product. If you notice any damage to the packaging, also check for damage to the product. If you notice any external damage to the unit or unexpected unusual functioning, do not continue to use the product. Immediately contact the dealer from whom you purchased the product or celexon directly (Web: www.celexon.co.uk, Mail: info@celexon.co.uk) for further information.
- The product may only be used in a dry and wind-free environment. It is only suitable for temporary outdoor use with appropriate safety measures to prevent it from falling over. (optionally available „celexon guy line set“ for use when setting up outdoors).
- Children under the age of 16 are not permitted to use the unit or its accessories.
- Ensure that no children play with the equipment or are in the vicinity without supervision.
- Conversion or modification of the product impairs product safety and is not permitted.
- Caution: Risk of injury! Never open the product without authorization. Never carry out repairs yourself!
- This product may only be used in its original manufacturer's condition and with any original accessories.
- Do not use the product in the vicinity of gas or water-conveying equipment or a dusty environment.
- Handle the product with care. It may be damaged by knocks, blows, or falling from even a small height.
- Keep the product away from moisture and heat.
- Never immerse the product in water or other liquids.
- Only use the product in its intended manner. Any other use may result in damage to the product or its surroundings.
- Tighten the screws but do not over-tighten them. Overtightening can cause damage and may affect the security of the screen.
- Failure to follow the above instructions may result in personal injury and damage to the product or equipment connected to it. Incorrect installation or use may also invalidate the warranty.
- If you are unsure about the use of the product, please contact your specialist personnel, your dealer, or celexon directly (Web: www.celexon.co.uk, Mail: info@celexon.co.uk)
- Technical changes and errors excepted.

The manufacturer accepts no responsibility for damage to property or personal injury if the screen is used outside the recommended specifications, or in the event of improper installation. Do not use this screen near heaters or air conditioners. Use the product in direct sunlight only to a limited extent, the PVC material may deform and affect flatness. If the screen is very warm after use in the sun, wait until it has cooled down to room temperature (approx. 18-24°) and is always completely dry before folding and packing it. We recommend that you keep the fabric in a warm room for a few hours in cold conditions to soften the material making it easier to fit. Please avoid any stains on the surface of the cloth. These may not be able to be removed.

Documents / Resources

	<p>celexon 0767 Folding Frame Screen [pdf] Instructions 0767 Folding Frame Screen, 0767, Folding Frame Screen, Frame Screen, Screen</p>
--	---

References

-  [High quality screens & accessories directly from the manufacturer | celexon.com](#)
-  [High quality screens & accessories directly from the manufacturer | celexon.com](#)
-  [High quality screens & accessories directly from the manufacturer | celexon.com](#)
-  [celexon | Smart Ideas for the bigger picture](#)
- [User Manual](#)

Manuals+. Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.