

# CEPTER

CESPECTRUM

Quick Start Guide

[www.ceptertech.com](http://www.ceptertech.com)



## Contents [ [hide](#) ]

- 1 Important Safety Notice:
- 2 Troubleshooting:
- 3 Device Layout:
- 4 Power Supply and Charging:
- 5 Cleaning, Maintenance, and Storage:
- 6 Packing List:
- 7 Technical information:
- 8 Documents / Resources
  - 8.1 References

## **Important Safety Notice:**



- Ensure vents are not blocked to prevent overheating.
- Avoid pressing the display hard or pinching it to lift the laptop.
- Use a protective case or bag when traveling with the laptop; avoid exposing it to the harsh conditions.
- Keep the laptop away from magnetic fields, direct sunlight, rain, and dew.
- Do not use in extreme heat or cold.
- Keep away from flames or heat sources.
- Do not tamper with the battery; keep it out of children's reach.
- Keep away from dust and corrosive chemicals.
- Use only original batteries; avoid non-original replacements.


## **Troubleshooting:**

If you encounter general issues with your laptop, follow these steps to resolve them:


- Ensure the laptop is completely turned off.
- Make sure the AC power adapter is securely connected to both the laptop and a working power outlet.
- Ensure all external devices are properly connected. If issues persist, try unplugging these devices to see if they are causing any errors.
- After turning off the laptop, wait for at least 10 seconds before attempting to power it back on. Check to ensure that the boot sequence is normal.

## **Device Layout:**






1. Camera
2. Camera LED
3. Mic
4. Power Button
5. keyboard
6. Touch Pad



1. Type-C

2. HDMI
3. USB 3.0
4. Type-C
5. Power-on LED
6. Battery Charge LED
7. Audio jack
8. USB 2.0
9. USB 3.0
10. Kensington-lock



## **Power Supply and Charging:**

- This device can be powered using either a lithium battery or an AC power adapter.
- After unpacking, please connect the AC power adapter to charge the laptop first.
- If you continue to use the laptop while charging, the charging time may be longer.
- For faster charging, it's recommended to put the laptop in sleep mode or turn it off while charging.
- When the battery is low, a prompt will appear on the screen. The laptop will continue to function until the battery is critically low, at which point data may not be saved. Please charge the device promptly; once connected to the adapter, you can use the laptop normally.

## **Cleaning, Maintenance, and Storage:**

- Before cleaning the device, turn off the system and unplug the adapter.
- Wipe the exterior with a damp cloth and dry it with a soft cloth.
- Do not use corrosive cleaning agents.
- Avoid immersing the product in water or other liquids.
- After cleaning, store the laptop in a dry, flat environment.

## Packing List:

1. Adapter \*1
2. Notebook computer \*1

## Technical information:

Model Number	CESPECTRUM
Screen Size	14 Inch
CPU	AMD Ryzen™ 5 6600H
Memory	16G RAM + 512G SSD
WIFI	WIFI6E/ 802.11 d/e/h/i/j/k/mc/r/v/w
Battery	11.55V, 5200mAh
Camera	1MP

## Power International AS,


PO Box 523, N-1471 Lørenskog, Norway

Power Norge: <a href="https://www.power.no/kundeservice/">https://www.power.no/kundeservice/</a> T: 21 00 40 00	Punkt 1 Danmark: <a href="https://www.punkt1.dk/kundeservice/">https://www.punkt1.dk/kundeservice/</a> T: 70 70 17 07
---	---

Expert Danmark: <a href="https://www.expert.dk/kundeservice/">https://www.expert.dk/kundeservice/</a> T: 70 70 17 07	Power Finland: <a href="https://www.power.fi/tuki/asiakaspalvelu/">https://www.power.fi/tuki/asiakaspalvelu/</a> T: 0305 0305
Power Danmark: <a href="https://www.power.dk/kundeservice/">https://www.power.dk/kundeservice/</a> T: 70 33 80 80	Power Sverige: <a href="https://www.power.se/kundservice/">https://www.power.se/kundservice/</a> T: 08 517 66 000

# CEPTER

## Documents / Resources

	<a href="#">CEPTER CESPECTRUM Scepter Spectrum OLED Laptop [pdf]</a> User Guide CESPECTRUM Scepter Spectrum OLED Laptop, CESPECTRUM, Scepter Spectrum OLED Laptop, Spectrum OLED Laptop, OLED Laptop, Laptop
---	---

## References

- [User Manual](#)

■ CEPTER

◆ CEPTER, CESPECTRUM, CESPECTRUM Scepter Spectrum OLED Laptop, Laptop, OLED Laptop, Scepter Spectrum OLED Laptop, Spectrum OLED Laptop

## Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.