



Home » CEPTER » CEPTER CFUSION27R5V3 All In One Computer User Manual 📆



CEPTER CFUSION27R5V3 All In One Computer User Manual




Thank you for choosing this AIO computer. Please read this instruction manual thoroughly before using and ensure you are familiar with the setup and operation of your new gaming gadget. Retain this instruction manual for future reference.

Contents [hide]

- 1 Appearance and Functions
- 2 Instructions
- 3 Frequently Asked Questions(FAQ) and Attentions
- 4 Technical Information
- 5 Documents / Resources
 - 5.1 References


Appearance and Functions

Front View




- 1. Display Screen
- 2. Aluminum Alloy Bracket
- 3. Webcam

Pack Contents



- 1. Keyboard ×1
- 2. Body ×1
- 3. Adapter ×1
- 4. Mouse ×1


Rear View



- 1. External DC Power Interface: This connection port supports 19V.
- 2. **HDMI OUT:** External Signal Output (The output display signal is connected to other external display devices.)
- 3. Ultra-fast Ethernet Interface: It can be connected to the Internet.
- 4. **USB Interface**: This connection interface supports devices with the specifications of USB 3.0/ USB2.0. This port can be connected with USB device.
- 5. **Microphone Interface:** This jack is the microphone connection port.
- 6. **Audio Output Interface:** This audio output jack supports earphones or 2.0-sound channel audio output devices.
- 7. **DP:** External Signal Output.

Instructions


Transport




When transporting the computer, you should tightly and firmly grasp or hold its body before lifting or putting down the computer

Install Bracket


1. Remove the base screw and lock the base to the bracket with screw.



2. Insert the top two clasps of the bracket into the corresponding card holes of the machine, and press the bracket downward to make the support stuck into the machine.




Connect the Power Supply




- 1. Connect the power adapter to the power cord.
- 2. Connect the power adapter to the corresponding interface on the back of the computer.
- 3. Connect the power cord to a properly grounded power outlet.

Connect the Mouse and Keyboard



**Connect the USB keyboard and mouse to the USB interface of the computer.

System Startup



*With the computer properly connected, press the power button on the back Panel of the computer to turn it on.

Frequently Asked Questions(FAQ) and Attentions

-[Network and Internet]- [Network and Sharing Center]-[Set up a new connection or network]-[Connect to The Internet], and then select the broadband called PPPoE; next, operate According to the system boot. If you get access to the Internet through other ways, Please contact the network service providers for the specific setting method." image-5="" headline-6="h2" question-6="Q7: How to establish or delete a wireless connection on your computer?" answer-6="A: If your computer is already installed the wireless network devices and wireless driver, the Windows operation system will automatically search for the wireless network which can be found in the notification area in the low right corner of the traditional desktop or in the R Sidebar. Check the strength of the wireless network signal, and fill in the password to access the wireless network, thus a connectionisestablished. If you no longer need the wireless network, select "disconnect" or "forget this network" for disconnection." image-6="" headline-7="h2" question-7="Q8: Startup Black Screen Troubleshooting" answer-7="A: 1.Press the power button, but no startup sound can be heard. Check if therein problem which the power line in your home. If there's no power failure, check whether the power cord are properly connected to the power supply or firmly plugged in the power socket. After checking and confirming, if nothing goes wrong, unplug the power cord from the power supply or socket. Then, in the case of power failure, press the power button 5 times continuously, with an interval of 1-2 seconds each time, and then connect the power cord and turn on the computer. If, still no startup sound can be heard, please contact the after-sales service for help. 2. After pressing the power button, there're startup sound but no images on the screen. Please press the power button for consecutive 5 seconds, then release your finder to turn off the computer. Check the power supply and all the cable connections according to the methods introduced in "1". Meanwhile, check if the cable connected to the computer is normal. After checking and confirming, if noting goes wrong, connect to the power and turn on the computer again; if it remains abnormal, please contact the after-sale service for help." image-7="" count="8" html="true" css class=""]

Technical Information

CFUSION27R5V3
27 Inch
16:9
2560 × 1440
AMD R5-7430U
AMD Radeon™ Graphics
8G RAM + 512G SSD
802.11ac/b/g/n
BT 5.0
3.0MP
Windows 11 Home
100-240V~ 50/60Hz 2.5A
19V/6.32A 120W









- Dispose of all packaging, paper, cartons and plastic bags in accordance with your local recycling regulations.
- At the end of the product's lifespan, please dispose of it separately from your household waste at an authorized household WEEE waste recycling centre.
- For more information, please contact the local authority or the retailer where you purchased the product.

Power Norge:

https://www.power.no/kundeservice/

T: 21 00 40 00

Expert Danmark:

https://www.expert.dk/kundeservice/

T: 70 70 17 07

Power Danmark:

https://www.power.dk/kundeservice/

T: 70 33 80 80

Punkt 1 Danmark:

https://www.punkt1.dk/kundeservice/

T: 70 70 17 07

Power Finland:

https://www.power.fi/tuki/asiakaspalvelu/

T: 0305 0305

Power Sverige:

https://www.power.se/kundservice/

T: 08 517 66 000



Documents / Resources



CEPTER CFUSION27R5V3 All In One Computer [pdf] User Manual CFUSION27R5V3, CFUSION27R5V3 All In One Computer, CFUSION27 R5V3, All In One Computer, Computer

References

- User Manual
 - All-in-One Computer, CEPTER, CFUSION27R5V3, CFUSION27R5V3 All In One Computer,
- CEPTER Computer

Leave a comment

Your email address will not be published. Required fields are marked* Comment * Name Email Website ☐ Save my name, email, and website in this browser for the next time I comment. **Post Comment** Search:

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

e.g. whirlpool wrf535swhz

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.

Search