



Ceptor Go TWS Earbuds User Manual

[Home](#) » [Ceptor](#) » Ceptor Go TWS Earbuds User Manual 

Ceptor Go TWS Earbuds User Manual



Contents

1 Using Instructions

1.1 Power on/off

1.2 Charging

1.3 Pairing

1.4 Managing music and personal assistant

1.5 Managing calls

1.6 Safety information

2 Specifications

3 Support

4 Documents / Resources

5 Related Posts

Using Instructions

Power on/off

To start the headset, take the earbuds out of the case. Place the earbuds back in the case to turn them off or press and hold the earbud for 2 seconds to Power on or 5 seconds to power off.

Charging

Connect the USB -C cable to the charging port on the case and a computer or a USB power adapter. There are four LED indicators that will light up inside the case to indicate the battery level. They will gradually fill up. Each earbud has a LED indicator that will turn on and shine red when they are being charged in the case. When the earbuds are fully charged the indicator will turn off.

Pairing

Open the case. Remove the earbuds, they will start blinking and pair together. Open Bluetooth settings on your device and find “**Ceptor Go**” and choose to connect. Pairing will occur automatically after this each time the earbuds are removed from the case.

Managing music and personal assistant

Press either of the earbuds once to play or pause music. Double-click the right earbud to raise the volume or the left to lower the volume. Triple-click the right earbud to go to the next song and the left earbud to play the previous song. Press and hold either earbud for 3 seconds to start the personal assistant on your device (Siri and Google Assistant).

Managing calls

Press either earbud once to answer or hang up a call. Press and hold either earbud for at least 3 seconds to reject an incoming call

Safety information

This product contains a rechargeable Li-po battery and the battery can not be replaced. To prevent possible hearing damage, do not listen at high volume levels for long periods.

Specifications

Bluetooth	5.0
Frequency	20 Hz – 20 KHz
Sensitivity	92 +/- 3 dB
Range	up to 10 m
Talk/play time	up to 3 h
Charge time (earbuds)	1.5 h
Charge time (case)	2 h, full battery last 3 charges
Charging	USB-C
Battery (earbuds / case)	Li-po 3.7 V, 40 mAh / 3.7 V, 300 mAh

Support


Website: www.roxcore.com

Box 50435, Malmo. Sweden

Version: 2020-06-24



Documents / Resources

	<p>Ceptor Go TWS Earbuds [pdf] User Manual Go TWS Earbuds, 23765</p>
---	--