



CHAINWAY MC50 Mobile Computer Installation Guide

[Home](#) » [CHAINWAY](#) » CHAINWAY MC50 Mobile Computer Installation Guide 

CHAINWAY MC50 Mobile Computer Installation Guide



Contents

1 Standard

1.1 Adapters

1.2 USB Cable

1.3 Battery

2 Optional

2.1 Charging Cradles

2.2 Pistol Grip

2.3 Adapters

3 Documents / Resources

4 Related Posts

Standard

Adapters

- **PWR-C50-5V2A-CN**



- **PWR-C50-5V2A-EU**



- **PWR-C50-5V2A-UK**



- **PWR-C50-5V2A-US**



Adapter (CN/EU/UK/US), I/P: 100-240V, O/P: 5V2A, use with DC-BK-TypeC cable

USB Cable

DC-BK-TypeC

1.0 meter Type-C cable



Battery

BTRY-C50-50MA

Main battery, 5000mAh Li-on battery, 3.85V output



Optional

Charging Cradles

CRD-C50-RBC

Single Charging Cradle, DC port, charge device only, use with DCPWR-12V2A-XX adapter.



CRD-C50-SCC

Single Charging Cradle, Type-C port, charge device only, use with 5V2A adapter



Pistol Grip

RB-C50-PS

Snap-On Trigger Handle and Rugged Boot Kit without battery, use with optional pistol battery.



Adapters

DCPWR-12V2A-CN/EU/UK/US

Adapter (CN/EU/UK/US), I/P:100-240V, Pistol O/P:12V2A, DC



Notice: Accessories items are subject to change without notice. Update Date: 06/14/2023

Address: 9F, Building2, Phase 2, Gaoxing Industrial Park, Liuxian 1st Rd., Bao'an District, Shenzhen, Guangdong 518102, China.

Email: sales@chainway.net

Web: <http://www.chainway.net>



Documents / Resources

	CHAINWAY MC50 Mobile Computer [pdf] Installation Guide MC50, MC50 Mobile Computer, Mobile Computer, Computer
---	---