





Changing touch F10-1 Smart Display Screen User Manual

Home » Changing touch » Changing touch F10-1 Smart Display Screen User Manual

Contents

- 1 Changing touch F10-1 Smart Display Screen
- **2 Product Usage Instructions**
- 3 Introduction
- **4 Function Introduction**
- 5 Package List
- 6 FAQ
- 7 Specifications
- 8 FCC
- 9 Documents / Resources
 - 9.1 References
- **10 Related Posts**



Changing touch F10-1 Smart Display Screen



Specifications

• Model: F10S

• Appearance: Black Plastic

• Screen size: 10.1 inch

• Resolution: 1280*800P

Color Gamut: 60% NTSCBrightness: 240CD/M2

• Speaker: 4/2W

Touch: Support (10 finger)Active Stylus: Support MPP

• Battery capacity: 3.8V/4000mAh

• FCC ID: 2BKBA-Frame

Product Usage Instructions

Main Interface

In the main interface, you will find the most used features. To access the menu, simply tap once on the screen.

Function Introduction

Setting: Clock, Alarm, Timer, Stopwatch, Bedtime

Display: Click to enter the time control selection. You can set the time range of day mode and night mode, and adjust the brightness of each mode.


Google Assistant

Control your frame via voice assistant by using Google Assistant.

Package List

- · Smart Display Stand
- USB to Type-C (For power supply)
- User Manual
- Adapter


Introduction




Main Interface

In the main interface you will find the most used features.

To access the menu, simply tap once on the screen.



The first time you start our product, please connect it to your wifi network and log in your google account



Function Introduction

Setting

- Clock
 Alarm, Clock, Timer, Stopwatch, Bedtime
- Display

Click to enter the time control selection you can set the time range of daymode and nightmode, and adjust the brightness of each mode.


 DayMode
 8.00
 18.00

 NightMode
 18.00
 6.00



For more product function explanations, please scan the QR code **Email:** <u>help@changingtouch.com</u>

Package List



FAQ

Questions	Answers
Startup&Shutdown	Hold down the power button for several seconds.
	Check if the battery is fully charged.
	2. Check the power adapter before restarting the frame again.
Frame can't boot	3. It is recommended to connect the adapter when using, and the battery is only used for short time entertainment.
	4. If it is still unable to boot after charging, please contact us.
	The frame screen is always on by default.
Extinguishing scree n	Please press the power button if you want to turn off the screen.
Undercharge	Reduce brightness appropriately.
	2. Reduce the volume appropriately.
Active Stylus Suppo	The frame supports MPP and USI protocol active stylus, but due to the different manufact urers of active stylus, the drawing effect will be different, and the actual effect shall prevail .
Home button lost	Please try rotating the frame to show.

Specifications

Model	F10S
Appearance	Black Plastic
Screen size	10.1 inch
Resolution	1280*800P
Color Gamut	60%NTSC
Brightness	240CD/M2
Speaker	4Ω/2W
Touch	Support (10 finger)
Active Stylus	Support MPP
Battery capacity	3.8V/4000mAh

FCC

FCC ID: 2BKBA-Frame

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. this device may not cause harmful interference, and
- this device must accept any interference received, including interference that may cause undesired operation.Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

FCC Radiation Exposure Statement

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must

not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provide with antenna installation instructions and transmitter operating conditions for satisfying RF exposure

Documents / Resources

USER MANUAL Flos Smart Display

<u>Changing touch F10-1 Smart Display Screen</u> [pdf] User Manual F10-1 Smart Display Screen, F10-1, Smart Display Screen, Display Screen, Screen

References

- 5 Changingtouch Smart Display Changing your Homelife!
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.