



Chauvet REM-RB50CM IP Curve User Guide

[Home](#) » [Chauvet](#) » Chauvet REM-RB50CM IP Curve User Guide 

Contents

- [1 Chauvet REM-RB50CM IP Curve](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Safety Notes](#)
- [5 What is Included](#)
- [6 Mounting](#)
- [7 Contact Us](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)



Chauvet REM-RB50CM IP Curve



Product Information

The product is the REM-RB50CM IP Curve. It is a lighting fixture that requires mounting and installation. The product comes with a Quick Reference Guide that provides important safety notes and instructions for use. The model ID of the product is REMRB50CMIPCURVE.

Mounting

Before mounting the REM-RB50CM IP Curve, it is essential to read the Safety Notes provided in the Quick Reference Guide. It is important to ensure that the mounting hardware used is capable of supporting the weight of the product. The Mounting Diagram shows the different components and their connections for proper installation:

- Alignment conical (x2)
- Male speego connection
- Rig Bar Speego
- Spring knob
- Tightening knob
- Locking bar
- Female speego connection (For use with Ground Support 2 Kit)
- Curve speego connection
- Locking latch

Product Usage Instructions

1. Scan the QR code provided to access the product page, warranty terms, and the complete User Manual.
2. Read the Safety Notes in the Quick Reference Guide before proceeding with installation and use.
3. Ensure that the mounting hardware used is capable of supporting the weight of the REM-RB50CM IP Curve.
4. Follow the Mounting Diagram provided in the Quick Reference Guide for proper alignment and connection of the different components.
5. If using the Ground Support 2 Kit, connect the female speego connection to the appropriate component.
6. Secure the product using the locking bar and locking latch for stability.
7. For any technical support or inquiries, contact Chauvet's Customer Support through the provided contact

information.

Safety Notes

These Safety Notes include important information about installation, use, and maintenance of the REM-RB50CM IP Curve.

DO NOT:

- Submerge this product (adhere to standards for the published IP rating). Regular outdoor operation is
- Permanently install outdoors in locations with extreme environmental This includes, but is not limited to:
 - Exposure to a marine/saline environment (within 3 miles of a saltwater body of water).
 - Locations where normal temperatures exceed the temperature ranges in this
 - Locations that are prone to flooding or being buried in
 - Other areas where the product will be subject to extreme radiation or caustic
- The maximum ambient temperature is 113 °F (45 °C). Do not operate this product at higher
- The minimum startup temperature is -4°F (-20°C). Do not start the product at lower
- The minimum ambient temperature is -22°F (-30°C). Do not operate the product at lower
- In the event of a serious operating problem, stop using immediately.


What is Included

- REM-RB50CM IP Curve
- Quick Reference Guide

Mounting

Before mounting this product, read the safety notes. Make sure the mounting hardware is capable of supporting the weight of the products.

Mounting Diagram



REM-RB50CM IP Curve Beknpte handleiding Rev. 1

Contact Us

General Information	Technical Support
Chauvet World Headquarters	
Address: 3360 Davie Rd. Davie, FL 33314 Voice: (954) 577-4455 Fax: (954) 929-5560 Toll Free: (800) 762-1084	Voice: (844) 393-7575 Fax: (954) 756-8015 Email: chauvetcs@chauvetlighting.com Website: www.chauvetprofessional.com
Chauvet U.K.	
Address: Pod 1 EVO Park Little Oak Drive, Sherwood Park Nottinghamshire, NG15 0EB UK Voice: +44 (0) 1773 511115 Fax: +44 (0) 1773 511110	Email: UKtech@chauvetlighting.eu Website: www.chauvetprofessional.eu
Chauvet Benelux	
Address: Stokstraat 18 9770 Kruishoutem Belgium Voice: +32 9 388 93 97	Email: BNLtech@chauvetlighting.eu Website: www.chauvetprofessional.eu
Chauvet France	
Address: 3, Rue Ampère 91380 Chilly-Mazarin France Voice: +33 1 78 85 33 59	Email: FRtech@chauvetlighting.fr Website: www.chauvetprofessional.eu
Chauvet Germany	
Address: Bruno-Bürgel-Str. 11 28759 Bremen Germany Voice: +49 421 62 60 20	Email: DEtech@chauvetlighting.de Website: www.chauvetprofessional.eu
Chauvet Mexico	
Address: Av. de las Partidas 34 - 3B (Entrance by Calle 2) Zona Industrial Lerma Lerma, Edo. de México, CP 52000 Voice: +52 (728) 690-2010	Email: servicio@chauvet.com.mx Website: www.chauvetprofessional.mx

Visit the applicable website above to verify our contact information and instructions to request support. Outside the U.S., U. K., Ireland, Mexico, France, Germany, or Benelux, contact the dealer of record.





Scan the QR code to access the product page, warranty terms, and the complete User Manual



REM-RB50CM IP Curve QRG Rev. 1

Documents / Resources

	<p>Chauvet REM-RB50CM IP Curve [pdf] User Guide REM-RB50CM IP Curve, REM-RB50CM, IP Curve, Curve</p>
	<p>CHAUVET REM-RB50CM IP Curve [pdf] User Guide REM-RB50CM IP Curve, REM-RB50CM, IP Curve, Curve</p>

References

- [▼ CHAUVET Professional](#)
- [▼ CHAUVET Professional](#)
- [▼ CHAUVET Professional](#)