



Cheerble M-CWJ01 Wicked Mouse PLUS User Manual

[Home](#) » [Cheerble](#) » Cheerble M-CWJ01 Wicked Mouse PLUS User Manual 

Contents


- [1 Cheerble M-CWJ01 Wicked Mouse PLUS](#)
- [2 IN THE BOX](#)
- [3 COMPONENTS](#)
- [4 HOW TO USE](#)
- [5 INDICATOR LIGHT INSTRUCTIONS](#)
- [6 HOW TO CHARGE](#)
- [7 PROMPT TONE INSTRUCTIONS](#)
- [8 SPECIFICATIONS](#)
- [9 FCC COMPLIANCE](#)
- [10 Documents / Resources](#)
- [11 Related Posts](#)




Cheerble M-CWJ01 Wicked Mouse PLUS



IN THE BOX



Wicked Mouse PLUS




USB Type-C Charging Cable



User Manual

COMPONENTS



HOW TO USE




Power on and select an interactive mode.

On / Off

Long press for 3 seconds

Short press to switch modes

A 'beep' sound will be heard as a short prompt, and after 5 seconds it will automatically confirm entering the current mode.



Tips

After entering the mode, short press to switch mode operation is invalid.

Check the product for damage before use. Please stop using it immediately to avoid harm to pets if the product is incomplete.

Supervision is required during the playtime to prevent your pet from swallowing.


INDICATOR LIGHT INSTRUCTIONS



Tips

1. Wicked Mouse PLUS will immediately start moving forward if it is touched while inactive.
2. Wicked Mouse PLUS will enter a 30-minute sleep period after 10 minutes of play-time. This is to avoid exhaustion and ensure moderate exercise for pets. If the Wicked Mouse PLUS is touched again while it's sleeping, it will end the rest early and continue to play with your pet.

HOW TO CHARGE



Before charging, please clean any foreign matter from the charging port and keep it dry.

Tips

If the Wicked Mouse PLUS experiences any of the following conditions, it indicates that the battery level is low and needs to be charged:


1. The light strip flashes red after being turned on and then automatically shuts down.
2. A 'beep-' sound is emitted with a long prompt tone and the light strip flashes red.
3. The function button does not respond when long pressed.

PROMPT TONE INSTRUCTIONS



Status	Regular 'beep--' sound with a long prompt tone, and the light strip flashes red.	Regular 'beep--' sound with a long prompt tone, and the light strip does not emit light.
Meaning	Low battery level.	Stuck for more than 10 minutes.
How to Unlock	Connect to power source or power off.	Touch to activate or power off.

SPECIFICATIONS



- Model: CWJ01
- Main materials: ABS, TPU, PVC
- Weight: 44 g / 1.6 oz
- Dimensions: 65 × 54 × 39 mm / 2.6 × 2.1 × 1.5 in (light strip not included)
- Battery: 200 mAh
- Input: 5V = 1A
- Operating temperature: 5°C-40°C / 41°F-104°F

LIABILITY TERMS

Advice for Use

Apart from playing with this product, it is recommended that you interact with your pet and provide a variety of play activities. Opportunities for stimulation or the appropriate amount of daily exercise should be determined by veterinarian.

Warranty

One-Year Limited Warranty

Cheerble warrants the included hardware product and accessories against defects in materials and workmanship for one year from the date of original retail purchase. Cheerble does not warrant against normal wear and tear, nor damage caused by accident or abuse. Complete details of the warranty applicable to this product and its terms can be found at www.cheerble.com.

Terms of Use and Limitation of Liability

1. Terms of Use

The use of this product is subject to your acceptance without modification of terms, conditions and notices contained with this product. Use of this product implies acceptance of all such terms, conditions, and notices. If you do not wish to accept these terms, conditions, and notices, please return the product, unused, in its original packaging and at your own cost and risk with proof of purchase for refund.

2. Proper Use

Proper use includes, without limitation, reviewing the entire user manual and any specific safety information statements. The specific temperament or size/weight of your pet may not be suitable for this product. If you are unsure whether this product is appropriate for your pet, please consult your veterinarian to use.

3. No Unlawful or Prohibited Use

This product is designed for use with pets only. This product is not intended to harm, injure or provoke. Using this product in a way that is not intended could result in violation of local laws.

4. Limitation of Liability

In no event shall Shenzhen Cheerble Technology Co., Ltd. or any of its associated companies be liable for (1) any direct, indirect, punitive, incidental, special or consequential damage and/or (i) any loss or damages whatsoever arising out of or connected with the use or misuse of this product.

5. Modification of Terms and Conditions

Shenzhen Cheerble Technology Co., Ltd. reserves the right to change the terms, conditions and notices governing this product from time to time. If such changes have been notified to you prior to your use of this product, they shall be binding on you as if incorporated herein.

FCC COMPLIANCE


This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer, or an experienced radio/TV technician for help.

Changes or modifications to this equipment not expressly approved by Shenzhen Cheerble Technology Co., Ltd. could void the user’s authority to operate the equipment.

Documents / Resources

	Cheerble M-CWJ01 Wicked Mouse PLUS [pdf] User Manual M-CWJ01 Wicked Mouse PLUS, M-CWJ01, Wicked Mouse PLUS, Mouse PLUS
---	---