

CHERRY
K4 Mechanical
Keyboard



Cherry K4 Mechanical Keyboard User Manual

[Home](#) » [CHERRY](#) » Cherry K4 Mechanical Keyboard User Manual 

Contents

- 1 Cherry K4 Mechanical Keyboard User Manual
- 2 PLUG-AND-PLAY
- 3 SETTINGS AND FUNCTIONS
- 4 RGB ILLUMINATION
- 5 OTHER USEFUL KEYS AND SHORTCUTS
- 6 TROUBLESHOOTING
- 7 References




Cherry K4 Mechanical Keyboard User Manual



PLUG-AND-PLAY

Connect the K4 to the USB port. Driver installation starts automatically.




SETTINGS AND FUNCTIONS

The K4 features a range of customization options and convenient quick keys. All settings are made directly on the


keyboard, by pressing the FN key + the desired setting key.

RGB ILLUMINATION



- Press FN + INS to start a cycle of shifting backlight colors.

•




- Press FN + HOME repeatedly to switch between 7 different background colors.


•




- Press FN + PGUP for LED illumination in 6 color zones. To set the color of each zone, press FN + PGUP again.




- When the NUM, CAPS, and SCROLL lights in the upper right corner blink, press FN + the numbers 1–6 repeatedly to adjust the colors.



- When you're done, press FN + PGUP again.




- Press FN + DEL repeatedly to switch between two different wave effects.




- Press FN + END once to start the 7-color breathing effect cycle, and twice to lock the breathing effect at the

current color.




- Press FN + PGDN to start a multi-color typing effect. (Visible when typing.)



- Press FN + the up/down arrow keys to increase/decrease the brightness of the LED lighting.
- Press FN + the left/right arrow keys to decrease/increase the speed of the LED effects.

OTHER USEFUL KEYS AND SHORTCUTS

FN + 	=	Lock Windows key
FN + F1–F8	=	Media controls
FN + F9	=	E-mail
FN + F10	=	Web browser
FN + F11	=	Lock all keys
FN + F12	=	Calculator

TROUBLESHOOTING

- Make sure the K4's USB connector is firmly attached to your computer's USB port.
- Connect to another USB port.
- Connect to another computer.
- Factory reset the keyboard by pressing and holding the FN key + backspace for 10 seconds.

NEED BACKUP?

If you have any questions, we're never more than an email away. Contact us at support@xtrfy.com
CHECK OUT MORE XTRFY PRODUCTS AT [XTRFY.COM](https://xtrfy.com)

Download PDF: [Cherry K4 Mechanical Keyboard User Manual](#)

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.