


# CHESONA HB309-V1 Multi Function Keyboard With Touchpad **Instruction Manual**

Home » CHESONA » CHESONA HB309-V1 Multi Function Keyboard With Touchpad Instruction Manual







#### **Contents**

- 1 Package Included
- 2 Pairing Steps
- 3 Charging your keyboard
- 4 No Backlight Keyboard
- **5 Specifications**
- 6 Backlight Keyboard
- 7 How to change the backlight color
- **8 Shortcut Keys Descrption**
- 9 Keyboard Indicator Overview
- 10 Indicator Light
- 11 Touchpad Gestures
- 12 Power Saving Mode
- 13 Troubleshooting
- 14 Support
- 15 Documents / Resources
  - 15.1 References
- **16 Related Posts**

## Package Included

- 1x Multi-Function Keyboard with Touchpad
- 1x Tablet Case
- 1x User manual


## **Pairing Steps**

- 1. Switch On/Off to on to turn your keyboard on.
- 2. Press the "Fn +C" keys together to enter pairing mode
- 3. Verify your device's Bluetooth settings are on Select Settings Bluetooth On
- 4. Select "Bluetooth Keyboard from your device's list of available devices to complete pairing.
- 5. Select "Bluetooth Keyboard", the indicator will turn off after successfully paired.

### Charging your keyboard

- 1. Plug the Type-C end of the charging cable into the keyboard and the other USB end into your preferred USB charger.
- 2. In charging, the power indicator will turn red. Generally, it takes approximately 2-3 hours for a full charge.

## No Backlight Keyboard




## **Specifications**


Working Current	s 7 5mA	Keyboard Working Voltage	3 0 V – 4 Z V
Touchpad working current	s 6mA	Working Time	*70 Hours
Battery Standby Time	z150 Days	Sleeping Current	< 40un
0har9in9 Port	TYPfi-C USB	8atte ry Capacity	200 mAh
Charging Time	2-3 Hours	Connect Distance	s 33 feet
Awaken Time	s2 Seconds	Charging Current	s200 mA
Working Temperature	-10°C – +5S°C	Key strength	50g -70g
Bluetooth Version	BT 5.0	Keyboard Size	9 86×6 85×0 23in‹h
TOuchpad	PixArt chip, with left and right click control ke^/board		

# **Backlight Keyboard**



## How to change the backlight color





## **Specifications**


Touchpad working cur lent	s 6mA	Bar klit Working Time	3Hours
Battery Standby Time	800 Oak	Sleep'ng Current	< 17uA
Charging Port	TYPE-C USB	Batter y Capacits	500mAh
Cha+ging Time	2 3 Hours	Connect Distance	s33 feet
Awaken Time	s2 Seconds	Charging Curgent	s200 mA
Working Temperature	ION – +55T	key strength	50g – 70g
Bluetath Version	BT 5 0	Keyboa+d Size	9 86×6 85x023inch
Touchpad	foxArt chip with left and right click concl keyboard		

## **Shortcut Keys Descrption**


#### NOTE:

- 1. The keyboard is compatible with three systems: Android, Windows, iOS When you connect the keyboard, it will automatically recognize your system and adjust it to the shortcut keys of the corresponding system.
- 2. When you need to connect to a device of another system, please disconnect the Bluetooth connection with the original device first
- 3. When using the shortcut keys, please hold the "Fn" key while pressing the desired shortcut key..


#### iOS:



#### Android:



## Windows:



# **Keyboard Indicator Overview**



## **Indicator Light**

The Status of the Keyboard	The Color of the Indi cator	The Status of the Indicator
Power Indicator	Red	The pQ^'et indicalor light 's on lot 3 seconde
Charging Indicator	Red	The red light for long time is charging status, when the lig ht turns green, the keyboard is fully charged
Low-Power Indicator	Red	The indicator light will flash slowly with red light:
Pairing Indicator	Blue	The indicator light will flash slowly with blue light v/hilepair ing and go out while pairing successfully
Caps Lock Indicator	Blue	Press the keyboard Caps Lock the Blue light is on

# **Touchpad Gestures**

The touchpad supports the touch gestures of iOS, Android and Windows system.

Gesture	Finger action picture	iOS 14.1	Win 10	Android
Single-finger tap	0	Mouse left button	Mouse left button	Mouse left button
Single-finger slide	-	Move the cursor	Move the cursor	Move the cursor
Quickly double-click for 3s without loose	<b>O</b> -	Left button select th e target to drag	Left button select th e target to drag	Left button select th e target to drag
Two-fingers tap	00	Mouse right button	Mouse right button	Mouse right button
Two-finger along a s traight line outward move	200	Zoom in	Zoom in	Zoom in
Two-finger along a s traight line inward m ove	200	Zoom out	Zoom out	Zoom out.
Two-finger vertical h orizontal movement-	-00-	Mouse wheel	Mouse wheel	Mouse wheel
Three-fingers slide up	199	Open the APP switc her	Open the window of Task browser	Open the APP Switcher
Three-fingers click	000	Mouse middle butto n	Open cortana	Switch Back
Three-fingers slide t o the left		Switch Active windo w	Switch Active windo w	Switch Active windo w

Three-fingers slide t o the right	000-	Switch Active windo w	Switch Active windo w	Switch Active windo w
Three fingers slide down	999	N/A	Show Desktop	Show Desktop
Four-fingers click	0000	Screenshot	Open Action Center	N/A

## **Power Saving Mode**

The keyboard will enter sleep mode when idle for 30 minutes. To activate it, press any key and wait for 3 seconds.

## **Troubleshooting**

## If the keyboard is not working correctly, please check the following:

- 1. The BT function on the tablet (or other BT devices) is enabled
- 2. The BT keyboard is within 33 feet
- 3. The BT keyboard is charged

If certain keys or commands begin to fail, work sporadically or lag in response time, please restart your tablet (power on and power off).

This fixes 99% of these types of issues. If a problem persists, please try the following steps:

- Delete all the BT devices on the tablet
- · Switch off the BT function on the tablet
- · Reboot the tablet
- · Switch on BT on the tablet
- Switch the keyboard off and on
- Repeat the steps on page 1 to connect the keyboard

## **Support**

If you have problems with keyboard usage or improvement opinions, please do not hesitate to contact us. We would love to get you taken care of and happy right away! Thank you!!!

#### **Documents / Resources**



CHESONA HB309-V1 Multi Function Keyboard With Touchpad [pdf] Instruction Manual HB309-V1, HB309-V1 Multi Function Keyboard With Touchpad, Multi Function Keyboard With Touchpad, Function Keyboard With Touchpad, Touchpad

## References

• User Manual

Manuals+,