



## Choetech T543-F Wireless Charging Mouse Pad User Manual

[Home](#) » [CHOETECH](#) » Choetech T543-F Wireless Charging Mouse Pad User Manual 

### Choetech T543-F Wireless Charging Mouse Pad



## Contents

- 1 Dear customer,
- 2 Parameters
- 3 Diagram
- 4 Instructions
- 5 APP download and use
- 6 Light Adjustment
- 7 Precautions
- 8 EU Declaration of Conformity
- 9 Documents / Resources
  - 9.1 References
- 10 Related Posts

## Dear customer,

Thank you for purchasing our product. Please read the following instructions carefully before first use and keep this user manual for future reference. Pay particular attention to the safety instructions. If you have any questions or comments about the device, please contact the customer line.

✉ [www.alza.co.uk/kontakt](mailto:www.alza.co.uk/kontakt)

☎ +44 (0)203 514 4411


**Importer** Alza.cz a.s., Jankovcova 1522/53, Holesovice, 170 00 Prague 7, [www.alza.cz](http://www.alza.cz)

## Parameters


**Input** 5V 12V 2A (max)

**Output** 15W (max)

## Diagram




## Instructions



1. Connect the USB charging cable to the power supply and mouse pad.
2. Place the device with a wireless charging receiver on the wireless charger of the mouse pad for charging.  
When charging, the charging indicator will be always blue, and the indicator will go off after removing the charging device.
3. Press the ON/OFF key to switch the light effect:
  - a. Press once to start and switch the light effect.
  - b. Double-click to enhance the luminous efficiency
  - c. Press for 3 seconds to shut down.

## APP download and use



1. Open the APP store on your mobile phone and search for “Tuya Smart” or scan the QR code to download and install.
2. Turn on mobile phone BZ and TUYA app, long press the power button for 3-5 seconds until I fast light flashes.  
Mouse pa will pair with app automatically.

## Light Adjustment

1. Manually adjust the light color and brightness.
2. Press lighting modes and custom lighting modes.
3. Music rhythm mode (1. Local mode to receive external music. 2. App mode to follow mobile phone music)
4. Power off based on preset timing.

## Precautions

- Please do not put magnetic cards (citizen ID card, bank card, etc.) with magnetic stripe or chip close to the product to avoid demagnetizing the card.
- Make sure your charging device support Qi wireless charging protocol or is installed with a wireless receiver that meets Qi standard.
- The fast charging function needs to be aided by the fast charger (exclusive in the package).
- Use the USB cable attached in the package. It is recommended to remove the mobile phone case during charging.
- Keep the charger and receiver away from water and other liquids.


## EU Declaration of Conformity

This equipment is in compliance with the essential requirements and other relevant provisions of EU directives.








# choetech

## Documents / Resources

	<a href="#">Choetech T543-F Wireless Charging Mouse Pad</a> [pdf] User Manual T543-F, T543-F Wireless Charging Mouse Pad, T543-F Charging Mouse Pad, Wireless Charging Mouse Pad, Charging Mouse Pad, Wireless Charging Pad, Mouse Pad
---	---

## References

-  [alza.at](#)
-  [Alza | Alza.co.uk](#)
-  [alza.de](#)
-  [alza.hu](#)
-  [alza.sk](#)