





# **Chompshop Project Patterns Toys and Games Owner's Manual**

Home » ChompShop » Chompshop Project Patterns Toys and Games Owner's Manual

#### **Contents**

- 1 Chompshop Project Patterns Toys and
- **2 INVENTOR'S CLUB**
- 3 MOUNTAIN FOLD
- **4 DOUBLE-SIDED TAPE**
- **5 REMOVE SURFACE**
- 6 FAQ
- 7 Documents / Resources
  - 7.1 References
- **8 Related Posts**



**Chompshop Project Patterns Toys and Games** 



## Inventor's Club

## **Toys & Games**

# Chompshop

**Warning:** Choking Hazard — Small parts not for children under 3 years or any individuals who have a tendency to place inedible objects in their mouths.

## **Specifications**

Item	Description
Snake Game	A game involving a winding path.
Skeeball	A game with a ramp and scoring holes.
Spinning Top and Launcher	A toy that spins when launched.

## **Tools Needed**

• Tape

## Instructions

- 1. Transfer patterns onto cardboard.
- 2. Punch holes as indicated.

- 3. Cut out shapes along the lines.
- 4. Make folds as shown.
- 5. Apply tape to secure parts.
- 6. Remove surfaces as needed.

#### **Symbols and Tips**

- If you see this symbol: Flute Direction Make sure that piece is glued with the arrow oriented correctly.
- Punch Hole: Use the indicated hole size.
- Cut Line: Follow the line for precise cutting.
- Combine your skills! Use both hole punch and cut techniques.

## **Folding Techniques**

- Mountain Fold: Fold the paper upwards.
- Valley Fold: Fold the paper downwards.

## **Double Sided Tape**

Front and back views of how to apply double-sided tape for secure attachment.

#### **Remove Surface**

Instructions on removing the surface layer of cardboard for certain parts.

#### **Recommended Order**

- 1. Transfer Patterns
- 2. Punch Holes
- 3. Cut Out Shapes
- 4. Make Folds
- 5. Apply Tape
- 6. Remove Surfaces

#### **Contact Information**

#### Chompshop


Copyright © 2024, by ChompShop, Inc., All rights reserved PO BOX 880, Narberth, PA 19072, USA


Email: hello@chompshop.com

## **INVENTOR'S CLUB**





**WARNING:** CHOKING HAZARD- Small parts not for children under 3 years or any individuals who have a tendency to place inedible objects in their mouths.












# CUT LINE














# **MOUNTAIN FOLD**




# **VALLEY FOLD**



**DOUBLE-SIDED TAPE** 



# **REMOVE SURFACE**



## recommended order

- 2. PUNCH HOLES
- 3. CUT OUT SHAPES
- 4. MAKE FOLDS
- 5. APPLY TAPE
- 6. REMOVE SURFACES



#### **FAQ**

1. What age is this toy suitable for?

This toy is not suitable for children under 3 years due to small parts.

2. What tools do I need to assemble the toys

You will need scissors, a glue stick, and tape.

3. Where can I find more details and tips?

Visit <u>www.chompshop.com/patterns</u> for more information.

Copyright © 2024, by ChompShop, Inc., All rights reserved PO BOX 880, Narberth, PA 19072, USA <a href="https://heb.com/heblo@chompshop.com">heblo@chompshop.com</a>

#### **Documents / Resources**



<u>Chompshop Project Patterns Toys and Games</u> [pdf] Owner's Manual v1.2.4, Project Patterns Toys and Games, Patterns Toys and Games, Games

## References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.